



201B 40/00C

Service
Service
Service



DDC/Power saving//TCO

Service Manual

TABLE OF CONTENTS

Horizontal frequencies
30 - 115 kHz

Description	Page	Description	Page
Important Safety Notice	2	Video(A2) Schematic Diagram	28
Technical Data	3	VideoPCB(A2)	29
Front control	4	Terminal(A1) Schematic Diagram & PCB (A1). 30	
OSD menu tree	5	Deflection(B) Schematic Diagram.	31
OSD Adjustments	6~12	PCB(B,C)..	32
Troubleshooting	12	Power Board(Diagram C) & MHR Panel(E)	33
Lock/Unlock, Factory mode & Service mode	13	Key controls and Panel PCB(D).	34
Warning and Notes	14	Repair Tips	35
Mechanical Instructions	15	Exploded View	36
Wiring Diagram	16	Recommended Parts List.	37
DDCDATA	17	SparePartsList.	38~41
DDC Instructions	18~22	Repair flow chart	42~49
Electrical Adjustments	23~25	General Product Specification.	50~80
Safety Test Requirements (Hipot & Ground)	26	General Troubleshooting Guide	81~103
Block Diagram	27		

SAFETY NOTICE

ANY PERSON ATTEMPTING TO SERVICE THIS CHASSIS MUST FAMILIARIZE HIMSELF WITH THE CHASSIS AND BE AWARE OF THE NECESSARY SAFETY PRECAUTIONS TO BE USED WHEN SERVICING ELECTRONIC EQUIPMENT CONTAINING HIGH VOLTAGES.

CAUTION: USE A SEPARATE ISOLATION TRANSFORMER FOR THIS UNIT WHEN SERVICING.

www.electronicsrepair.net

GB 3138 106 10205

飛利浦



PHILIPS



Go to cover page

Proper service and repair is important to the safe, reliable operation of all Philips Consumer Electronics Company** Equipment. The service procedures recommended by Philips and described in this service manual are effective methods of performing service operations. Some of these service operations require the use of tools specially designed for the purpose. The special tools should be used when and as recommended.

It is important to note that this manual contains various CAUTIONS and NOTICES which should be carefully read in order to minimize the risk of personal injury to service personnel. The possibility exists that improper service methods may damage the equipment. It also is important to understand that these CAUTIONS and NOTICES ARE NOT EXHAUSTIVE. Philips could not possibly know, evaluate and advise the service trade of all conceivable ways in which service might be done or of the possible hazardous consequences of each way. Consequently, Philips has not undertaken any such broad evaluation. Accordingly, a servicer who uses a service procedure or tool which is not recommended by Philips must first satisfy himself thoroughly that neither his safety nor the safe operation of the equipment will be jeopardized by the service method selected.

* * Hereafter throughout this manual, Philips Consumer Electronics Company will be referred to as Philips.

WARNING

Critical components having special safety characteristics are identified with a  by the Ref. No. in the parts list and enclosed within a broken line* (where several critical components are grouped in one area) along with the safety symbol  on the schematics or exploded views.

Use of substitute replacement parts which do not have the same specified safety characteristics may create shock, fire, or other hazards.

Under no circumstances should the original design be modified or altered without written permission from Philips. Philips assumes no liability, express or implied, arising out of any unauthorized modification of design. Servicer assumes all liability.

TO ENSURE THE CONTINUED RELIABILITY OF THIS PRODUCT, USE ONLY ORIGINAL MANUFACTURER'S REPLACEMENT PARTS, WHICH ARE LISTED WITH THEIR PART NUMBERS IN THE PARTS LIST SECTION OF THIS SERVICE MANUAL.

* Broken Line 

[Go to cover page](#)

Technical Specification*

CRT

Size and deflection :21 inch/51cm,90°deflection angle
Dot pitch/Grille pitch : 0.25mm
Horizontal pitch : 0.21mm

Tube type : Shadow mask,super high contrast, antiglare, anti-static, anti-reflection, light transmission 43%

Phosphor : P22

Recommended display area : 15.4"x11.6"/392 x 294 mm

Maximum display area : 16.0"x12.0"/406 x 305 mm

Scanning

Horizontal scanning : 30 - 115 KHz
Vertical scanning : 50 - 160 Hz

Video

Video dot rate : 297 Mhz
Input impedance
-Video : 75 Ohm
- Sync : 2.2 kOhm
Input signal levels : 0.7Vpp
Separate sync
Sync input signal : Composite sync
Sync polarities : Positive and negative

White Color Temperature

Chromaticity CIE coordinates:
at 9300 °k x = 0.283 y = 0.297
6500 °k x = 0.313 y = 0.329
5500 °k x = 0.332 y = 0.347

Physical Specifications

Dimensions : 482x476x467mm(including base)
482x437x428mm(excluding base)
weight : 23.5 Kg


Power supply : 90 - 264 VAC, 50/60HZ
Power consumption : <160 Watt

Operating condition
Temperature : 0 °C - 35 °C
Relative Humidity : 10 % - 90 %

Storage condition
Temperature : - 25 °C - 65 °C
Relative Humidity : 5 % - 95 %

Pin assignment :

The 15-pin D-sub connector(male) of the signal cable (IBM systems) :



Pin No.	Assignment	Pin No.	Assignment
1	Red video input	9	No pin
2	Green video input	10	Logic ground
3	Blue video input	11	Identical output - Connected to pin 10
4	Identification output - Connected to pin 10	12	Serial data line(SDA)
5	Ground	13	H.Sync /H+V
6	Red video ground	14	V.Sync(VCLK for DDC)
7	Green video ground	15	Data clock line(SCL)
8	Blue video ground		

Data Storage(Resolution Modes)Factory preset modes:

This monitor has 34factory-preset modes as indicates in the following table:

Mode	Resolution	Frequency	Sync. polarity	
		H(KHz) / V(Hz)	H	V
1	640 X 480	31.469KHz/59.941 Hz	-	-
2	720 X 400	31.468KHz/70.084 Hz	-	+
3	640 X 480	37.5 KHz/75Hz	-	-
4	640 X 480	37.861 KHz/72.810 Hz	-	-
5	800 X 600	37.879 KHz/60.317 Hz	+	+
6	640 X 480	43.269 KHz/85.008 Hz	-	-
7	800 X 600	46.875 KHz/75.000 Hz	+	+
8	800 X 600	48.077 KHz/72.188 Hz	+	+
9	1024 X 768	48.363KHz/60.004Hz	-	-
10	832 X 624	49.722 KHz/74.546Hz	+	+
11	640 X 480	50.628 KHz/100.10 Hz	-	-
12	800 X 600	53.674 KHz/85.061 Hz	+	+
13	1024 X 768	56.476 KHz/70.069 Hz	-	-
14	1024 X 768	60.023KHz/75.029Hz	+	+
15	800 X 600	63.923 KHz/100.00 Hz	+	+
16	1280 X 1024	63.981KHz/60.020Hz	+	+
17	1024 X 768	68.677KHz/84.997Hz	+	+
18	1152 X 870	68.681KHz/74.979Hz	-	-
19	1600 X 1200	75.000 KHz/60.000 Hz	+	+
20	1280 X 1024	79.976KHz/75.024Hz	+	+
21	1600 X 1200	81.250 KHz/65.000 Hz	+	+
22	1792X 1344	83.640 KHz/59.999 Hz	+	+
23	1856X 1392	86.333 KHz/59.995 Hz	+	+
24	1600 X 1200	87.500 KHz/70.000 Hz	+	+
25	1920X 1440	90.000 KHz/60.000 Hz	+	+
26	1280 X 1024	91.146KHz/85.024Hz	+	+
27	1600 X 1200	93.750KHz/75.000Hz	+	+
28	1600 X 1200	106.250KHz/85.000Hz	+	+
29	1792 X 1344	106.270 KHz/74.997 Hz	+	+
30	1920 X 1440	112.5 KHz/75 Hz	+	+
31	1856 X 1392	109.950KHz/75 Hz	+	+
32	1792 X 1344	114.048KHz/81 Hz	+	+
33	1280 X 1024	115.236KHz/106.7 Hz	+	+
34	1600 X 1200	115.238KHz/91.758 Hz	+	+

Automatic Power Saving

If you have VESA's DPMS compliance display card or software installed in your PC,the monitor can automatically reduce its power consumption when not in use. And if an input from a keyboard, mouse or other input devices is detected, the monitor will automatically "wake up". The following table shows the power consumption and signalling of this automatic power saving features :

Power Management Definition						
VESA's mode	VIDEO	H-SYNC	V-SYNC	POWER USED	POWER SAVING(%)	LED COLOR
ON	Active	Yes	Yes	< 112 W	0 %	Green
Stand-by	Blanked	No	Yes	< 2 W	97 %	Yellow
Suspend	Blanked	Yes	No	< 2 W	97 %	Yellow
OFF	Blanked	No	No	< 2 W	97 %	Amber

This monitor is Energy Star® compliant .As an ENERGY STAR® Partner, PHILIPS has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.




201B4 M25P


Installation

Go to cover page

Front View



Rear View



Power button switches your monitor on.



OK button which when pressed will take you to the OSD controls



Contrast hotkey. When the UP arrow is pressed, the adjustment controls for the CONTRAST will show up.



UP and DOWN buttons are used when adjusting the OSD of your monitor



Brightness hotkey. When the RIGHT arrow is pressed, the adjustment controls for BRIGHTNESS will show up.



LEFT and RIGHT buttons, like the UP and DOWN buttons, are also used in adjusting the OSD of your monitor.



By pressing both the UP and OK buttons, you can easily access the Input Signals A and/or B.

1. D-Sub Port - Attach the D-Sub connector that comes with your monitor here. Other end connects to your PC.


2. Power in - Attach power cable here.

3. BNC Connectors - Attach the connectors here to get the best video performance from your monitor.

The OSD Tree

Below is an overall view of the structure of the On-Screen Display. You can use this as reference when you want to later on work your way around the different adjustments.

CRT OSD tree / English



* Specifications are subject to change without prior notice.



OSD Adjustments

Go to cover page





The OSD Controls

BRIGHTNESS

To adjust your screen's brightness, follow the steps below. Brightness is the overall intensity of the light coming from the screen. A 50% brightness is recommended.

- 1) Press the  or  button on the monitor. The BRIGHTNESS window appears.






- 2) Press the  or  button to adjust the brightness.
- 3) When the brightness is adjusted to the level desired, stop pressing the  or  button and after three seconds the BRIGHTNESS window will disappear with the new adjustment saved.





Smart Help After the BRIGHTNESS window has disappeared, to continue to the CONTRAST window, follow the steps under CONTRAST.

CONTRAST

To adjust your screen's contrast, follow the steps below. Contrast is the difference between the light and dark areas on the screen. A 100% contrast is recommended.

- 1) Press the  or  button on the monitor. The CONTRAST window appears.





- 2) Press the  or  button to adjust the contrast.
- 3) When the contrast is adjusted to the level desired, stop pressing the  or  button and after three seconds the CONTRAST window will disappear with the new adjustment saved.



Smart Help After the CONTRAST window has disappeared, to continue to the MAIN CONTROLS, follow the steps under LANGUAGE

LANGUAGE


The ON SCREEN DISPLAY shows its settings in one of five languages. The default is English, but you can select French, Spanish, German, or Italian.

- 1) Press the  button on the monitor. The MAIN CONTROLS window appears. LANGUAGE should be highlighted.
- 2) Press the  button again. The LANGUAGE window appears.





- 3) Press the  or  button until the desired language is highlighted.



- 4) Press the  button to confirm your selection and return to MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted...



Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to INPUT SIGNAL SELECTION, press the  button until INPUT SIGNAL SELECTION is highlighted. Next, follow steps 3 - 5 under INPUT SIGNAL SELECTION.


. . . to exit completely, press  the button


INPUT SIGNAL SELECTION (Not available in all models)




INPUT SIGNAL SELECTION determines what you see on the screen. The default setting is INPUT A, but if the video input signal is different than the output signal, you may want to change it to INPUT B.?

- 1) Press the  button on the monitor. The MAIN CONTROLS window appears.
- 2) Press the  button until INPUT SIGNAL SELECTION is highlighted.





- 3) Press the  button. The INPUT SIGNAL SELECTION window appears.



- 4) Press the  or  button to highlight INPUT B or INPUT A.
- 5) Press the  button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.


After returning to MAIN CONTROLS . . .


. . . to continue to ZOOM, press the  button until ZOOM is highlighted. Next, follow steps 3 - 5 under ZOOM.

. . . to exit completely, press the  button


ZOOM


ZOOM increases or decreases the size of the images on your screen. To adjust the ZOOM follow the steps below.



1) Press the  button on the monitor. The MAIN CONTROLS window appears.


2) Press the -button until ZOOM is highlighted.




3) Press the  button. The ZOOM window appears.




4) Press the  or  button to adjust ZOOM.

5) Press the  button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.


Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST HORIZONTAL, press the  button until ADJUST HORIZONTAL is highlighted. Next, follow steps 3 - 7 under ADJUST HORIZONTAL.

. . . to exit completely, press the  button

ADJUST HORIZONTAL

ADJUST POSITION under ADJUST HORIZONTAL shifts the image on your screen either to the left or right. Use this feature if your image does not appear centered. ADJUST SIZE under ADJUST HORIZONTAL expands or controls the image on your screen, pushing it out toward the left and right sides or pulling it in toward the center.

1) Press the  button on the monitor. The MAIN CONTROLS window appears.



2) Press the  button until ADJUST HORIZONTAL is highlighted.




3) Press the  button. The ADJUST HORIZONTAL window appears. ADJUST POSITION should be highlighted.




4) Press the  or  button to move the image to the left or right.


5) When the position is adjusted, press the  button to return to MAIN CONTROLS window, or press the  to highlight ADJUST SIZE.



6) To adjust the horizontal size, press the  or  button.

7) When the size is adjusted, press the  button to return to MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.


Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST VERTICAL, press the  button until ADJUST VERTICAL is highlighted. Next, start with step 3 under ADJUST VERTICAL and follow the directions.

. . . to exit completely, press the  button

ADJUST VERTICAL

ADJUST POSITION under ADJUST VERTICAL shifts the image on your screen either up or down. Use this feature if your image does not appear centered. ADJUST SIZE under ADJUST VERTICAL expands or controls the image on your screen, pushing it out toward the top or bottom or pulling it in toward the center.


1) Press the  button on the monitor. The MAIN CONTROLS window appears.


OSD Adjustments



Go to cover page



- 2) Press the  button until ADJUST VERTICAL is highlighted.






- 3) Press the  button. The ADJUST VERTICAL window appears. ADJUST POSITION should be highlighted.




- 4) Press the  or  button to move the image up or down.


- 5) When the position is adjusted, press the  button to return to MAIN CONTROLS window, or press the  to highlight ADJUST SIZE.




- 6) To adjust the vertical size, press the  or  button.

- 7) When the size is adjusted, press the  button to return to MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS . . .


. . . to continue to ADJUST SHAPE, press the  button until ADJUST SHAPE is highlighted. Next, start with step 3 under ADJUST SHAPE and follow the directions.

. . . to exit completely, press the  button

ADJUST SHAPE


ADJUST SIDE CURVE


ADJUST SIDE CURVE under ADJUST SHAPE allows you to adjust two of the five preset options. These two options are PINCUSHION and BALANCED pincushion. Note: use these features only when the picture is not square.

- 1) Press the  button on the monitor. The MAIN CONTROLS window appears.


- 2) Press the  button until ADJUST SHAPE is highlighted.





- 3) Press the  button. The ADJUST SHAPE window appears. ADJUST SIDE CURVE should be highlighted.






- 4) Press the  button. The SIDE CURVE window appears. PINCUSHION should be highlighted.






- 5) To adjust the pincushion, press the  or  button.

- 6) When the pincushion is adjusted, press the  button to highlight BALANCED or press the  button to return to the ADJUST SHAPE window.




- 7) To adjust the balanced pincushion, press the  or  button.


- 8) When the balanced pincushion is adjusted, press the  button to return to the ADJUST SHAPE window. BACK TO MAIN WINDOWS will be highlighted.


- 9) Press the  button to return to the MAIN CONTROLS window, or press the  button until ADJUST SIDE ANGLES is highlighted.

Smart Help After returning to MAIN CONTROLS . . .

...to continue to ADJUST SIDE ANGLES, start with step 5 under ADJUST SIDE ANGLES and follow the directions.


...to exit completely, press the  button twice.

...to adjust only the BALANCED pincushion, follow steps 1 - 4 above, then press the  button, and follow steps 7 - 9.

...to adjust only the PARALLELOGRAM, follow steps 1 - 4 above, then press the  button, and follow steps 7 - 9


ADJUST SIDE ANGLES


ADJUST SIDE ANGLES under ADJUST SHAPE allows you to adjust two of the five preset options. These two options are TRAPEZOID and PARALLELOGRAM. Note: use these features only when the picture is not square.

1) Press the  button on the monitor. The MAIN CONTROLS window appears.

2) Press the  button until ADJUST SHAPE is highlighted.






3) Press the  button. The ADJUST SHAPE window appears. ADJUST SIDE CURVE should be highlighted.






4) Press the  button to highlight ADJUST SIDE ANGLES.

5) Press the  button. The SIDE ANGLES window appears. TRAPEZOID should be highlighted.






6) To adjust the trapezoid, press the  or  button. SHAPE window.

7) When the trapezoid is adjusted, press the  button to highlight PARALLELOGRAM or press the  button to return to the ADJUST




8) To adjust the parallelogram, press the  or  button.


9) When the parallelogram is adjusted, press the  button to return to the ADJUST SHAPE window. BACK TO MAIN WINDOWS will be highlighted.

10) Press the  button to return to the MAIN CONTROLS window, or press the  button until ROTATE IMAGE is highlighted.

Smart Help After returning to MAIN CONTROLS . . .


...to continue to ROTATE IMAGE, start with step 5 under ROTATE IMAGE and follow the directions.

...to exit completely, press the  button twice.

...to adjust only the PARALLELOGRAM, follow steps 1 - 4 above, then press the  button, and follow steps 7 - 9


ROTATE IMAGE

ROTATE IMAGE under ADJUST SHAPE allows you to adjust one of the five preset options. These two options are PINCUSHION and BALANCED pincushion. Note: use this feature only when the picture is not square.


1) Press the  button on the monitor. The MAIN CONTROLS window appears.

2) Press the  button until ADJUST SHAPE is highlighted.



3) Press the  button. The ADJUST SHAPE window appears. ADJUST SIDE CURVE should be highlighted.


4) Press the  arrow until ROTATE IMAGE is highlighted.



OSD Adjustments

Go to cover page

5) Press the button. The ROTATE IMAGE window appears. ROTATE should be highlighted.



6) To adjust the rotation, press the or button.

7) When the rotation is adjusted, press the button to return to the ADJUST SHAPE window. BACK TO MAIN CONTROLS should be highlighted.

8) Press the button to return to MAIN CONTROLS.

Smart Help After returning to MAIN CONTROLS . . .

. . . to continue to ADJUST COLOR, press the button until ADJUST COLOR is highlighted. Next, start with step 3 under ADJUST COLOR and follow the directions.

...to exit completely, press the button twice.

ADJUST COLOR

Your monitor has two preset options you can choose from. The first option is for GENERAL USE, which is fine for most applications. The second option is for GAMES, which is for playing computer games. When you select one of these options, the monitor automatically adjusts itself to that option. There is also a third option, USER PRESET, which allows you to adjust the colors on your screen to a setting you desire.

1) Press the button on the monitor. The MAIN CONTROLS window appears.

2) Press the button until ADJUST COLOR is highlighted.



3) Press the button. The ADJUST COLOR window appears.



4) Press the or button to highlight 9300K for GENERAL USE, 6500K for GAMES, or USER PRESET.

5) Once you have highlighted GENERAL USE or GAMES, press the button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.



6a) If USER PRESET is highlighted, press the button to highlight RED. Next, press the LEFT CURSOR or RIGHT CURSOR button to adjust the color red.

6b) When finished with RED, press the button to highlight GREEN. Next, press the or button to adjust the color green.

6c) When finished GREEN, press the button to highlight BLUE. Next, press the or button to adjust the color blue.

6d) When all adjustments are complete, press the button to confirm your adjustments and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS. . .

. . . to continue to RESET TO FACTORY SETTINGS, press the button until RESET TO FACTORY SETTINGS is highlighted. Next, start with step 3 under RESET TO FACTORY SETTINGS.

. . . to exit completely, press the button.

RESET TO FACTORY SETTINGS

RESET TO FACTORY SETTINGS returns everything in all the windows to factory presets.



1) Press the button on the monitor. The MAIN CONTROLS window appears.


2) Press the button until RESET TO FACTORY SETTINGS is highlighted.




3) Press the button. The RESET TO FACTORY SETTINGS window appears.


Go to cover page


- 4) Press the  or  button to select YES or NO. NO is the default. YES returns all settings to their original factory adjustments.



- 5) Press the  button to confirm your selection and return to the MAIN CONTROLS window. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS...

... to continue to EXTRA CONTROLS, press the  button until EXTRA CONTROLS is highlighted. Next, start with step 3 under EXTRA CONTROLS.

... to exit completely, press the  button.

EXTRA CONTROLS


ADJUST MOIRE


EXTRA CONTROLS is a set of three features, including ADJUST MOIRE. Moire is a fringe pattern arising from the interference between two superimposed line patterns. To adjust your moire, follow the steps below. Note: Use only if necessary. By activating ADJUST MOIRE, sharpness can be affected.


- 1) Press the  button on the monitor. The MAIN CONTROLS window appears.


- 2) Press the DOWN CURSOR button until EXTRA CONTROLS is highlighted.






- 3) Press the  button. The EXTRA CONTROLS window appears. will ADJUST MOIRE will be highlighted.






- 4) Press the  button. The ADJUST MOIRE window appears. HORIZONTAL will be highlighted.




- 5) To adjust the horizontal moire, press the  or  button.


- 6) When the horizontal moire is adjusted, press the  button to highlight VERTICAL.




- 7) To adjust the vertical moire, press the  or  button.

- 8) When the vertical moire is adjusted, press the  button to return to the EXTRA CONTROLS window. BACK TO MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS...



... to continue to DEGAUSS, press the  button until DEGAUSS is highlighted. Next, start with step 3 under EXTRA CONTROLS, DEGAUSS.

... to exit completely, press the  button.



Go to cover page

DEGAUSS


EXTRA CONTROLS is a set of three features, including DEGAUSS. Degaussing removes electromagnetic build up that may distort the color on your screen.


- 1) Press the  button on the monitor. The MAIN CONTROLS window appears.
- 2) Press the  button until EXTRA CONTROLS is highlighted.



- 3) Press the  button. The EXTRA CONTROLS window appears. ADJUST MOIRE will be highlighted.
- 4) Press the  button until DEGAUSS is highlighted.



- 5) To degauss your screen, press the  button. Your screen will be degaussed, then the MAIN CONTROLS window will reappear. CLOSE MAIN CONTROLS will be highlighted.

Smart Help After returning to MAIN CONTROLS . . .
 . . . to exit completely, press the  button.

CLOSE MAIN CONTROLS**Monitor Specific Troubleshooting****Self-Test Feature Check (STFC)**

Your monitor provides a self-test feature that allows you to check whether your monitor is functioning properly. If your monitor and computer are properly connected but the monitor screen remains dark, run the monitor self-test by performing the following steps:

1. Turn off both your computer and the monitor.
2. Unplug the video cable from the back of the computer.
3. Turn on the monitor.

If the monitor is functioning properly, you will see a OSD message as shown in the following illustration:

ATTENTION
CHECK SIGNAL CABLE

This box also appears during normal system operation if the video cable becomes disconnected or damaged. This box will remain on for one minute, go off five seconds, then on for one minute, and will repeat cycle.

1. Turn off your monitor and reconnect the video cable; then turn on both your computer and the monitor.
2. While in self-test mode, the LED remains green and the pattern remains on and stationary.


If your monitor screen still remains dark after you use the previous procedure, check your video controller and computer system; your monitor is functioning properly.

NO SIGNAL INPUT

If there is something wrong with the input signal, a message appears on the screen although the power indicator LED is still on. The message may indicate that the monitor is NO SIGNAL INPUT or that you need to check the signal cable.

ATTENTION
NO SIGNAL INPUT

Front Control



- Power button switches your monitor on.
- OK button which when pressed will take you to the OSD controls
- Contrast hotkey. When the UP arrow is pressed, the adjustment controls for the CONTRAST will show up.
- UP and DOWN buttons are used when adjusting the OSD of your monitor
- Brightness hotkey. When the RIGHT arrow is pressed, the adjustment controls for BRIGHTNESS will show up.
- LEFT and RIGHT buttons, like the UP and DOWN buttons, are also used in adjusting the OSD of your monitor.

OSD Lock


OSD lock is a feature which disables the OSD controls. It can be used when the monitor is set up for demonstration purposes or when adjustment of the OSD is not desirable.

Switch on OSD lock feature:

Press and hold the button continuously for 15 seconds.

Release the button when the message

"CONTROL MENU IS LOCKED" appears.



Switch off OSD lock feature:

Press and hold the button continuously for 15 seconds or until the message window "CONTROL MENU IS LOCKED" disappears, and "MAIN CONTROLS" appears.




Default setting of MODEL SELECT (Do not change it.)

MODEL SELECT	
	115K 201B4
	111K 109P4
	130K 202P4
	RESERVE
	RESERVE
	SWDDC

To access factory mode

1. Turn off monitor (don't turn off PC)
2. Press " " and "" simultaneously on the front control panel, then press "", wait till the OSD menu with characters CM25 PLUS V0.70 20020115 (below OSD menu)" come on the screen of monitor.

Factory Mode Indicator



3. If OSD menu disappears on the screen of monitor, press "" again (anytime), then the OSD menu comes on the screen again.
4. Using " " : to select OSD menu.
5. Using " " : to increase or decrease the setting.
6. Using "" to access/confirm the selection.

To leave factory mode

7. After alignment of factory mode, turn off monitor (if you do not turn off monitor, the OSD menu is always at the factory mode), then turn on monitor again (at this moment, the OSD menu goes back to user mode).

To access BURN IN mode

First of all, monitor displays an image.

1. Disconnect the video cable (interface cable).
2. Turn off monitor
3. Press " " and "" simultaneously on the front control panel, then the BURN IN mode comes on the screen of monitor as below.

50 seconds around




5 seconds around



repeatedly

4. Reconnect the video cable, then return to normal image.



SERVICE MODE (Indication-Factory mode)



00010: stands for

1. using 10 hours already.
2. turn on/off 10 times.
3. using several hours + turn on/off monitor.

Warnings

1. Safety regulations require that the unit should be returned in its original condition and that components identical to the original components are used. The safety components are indicated by the symbol .
2. In order to prevent damage to ICs and transistors, all high-voltage flash-overs must be avoided. In order to prevent damage to the picture tube, the method shown in Fig. 1 should be used to discharge the picture tube. Use a high-voltage probe and a multimeter (position DC-V). Discharge until the meter reading is **0 V** (after approximately 30 seconds).
3. **ESD** 
All ICs and many other semiconductors are sensitive to electrostatic discharges (ESD). Careless handling during repair can drastically shorten their life. Make sure that during repair you are connected by a pulse band with resistance to the same potential as the ground of the unit. Keep components and tools also at this same potential.
4. When repairing a unit, always connect it to the AC Power voltage via an isolating transformer.
5. Be careful when taking measurements in the high-voltage section and on the picture tube panel.
6. It is recommended that safety goggles be worn when replacing the picture tube.
7. When making adjustments, use plastic rather than metal tools. This will prevent any short-circuit or the danger of a circuit becoming unstable.
8. Never replace modules or other components while the unit is switched on.
9. Together with the deflection unit, the picture tube is used as an integrated unit. Adjustment of this unit during repair is not recommended.
10. After repair, the wiring should be fastened in place with the cable clamps.
11. All units that are returned for service or repair must pass the original manufacturer's safety tests.

Notes

1. The direct voltages and waveforms are average voltages. They have been measured using the Service test software and under the following conditions :
 - Mode : 640 * 480 (31.5kHz / 60Hz)
 - Signal pattern : grey scale
 - Adjust brightness and contrast control for the mechanical mid-position (click position)
2. The picture tube panel has printed spark gaps. Each spark gap is connected between an electrode of the picture tube and the Aquadag coating.
3. The semiconductors indicated in the circuit diagram(s) and in the parts lists are completely interchangeable per position with the semiconductors in the unit, irrespective of the type indication on these semiconductors.




Fig.1

0. Location of the panel

0.1 Main panel (1160)

0.2 Video panel (1161)

1. General

To be able to perform measurements and repairs on the "circuit boards", the monitor should be placed in Service Position (fig. 1) first:

How to remove the back cover of monitor :

There are 2 screws in the lid [1 screw are at the right side of the monitor, The other 1 screw are at the left side of the monitor],to fix the front cabinet and back cover of the monitor.

Step 1:To open the lid at the right-upper side and 1screw in right-downer side of the monitor.(FIG.3)

Step 2:To open the lid at the left-upper side and 1screw in left-downer side of the monitor.(FIG.4)

Step 3:To remove the backcover, you can see FIG.5

Step 4:To remove the 16 screws on the metal shield, and remove the metal shield, you can see FIG.6.

Chassis :

- After remove the back cover & metal shield, you can see the inside of the monitor as Fig. 6.
- To remove 13 screws for service position as Fig. 6 to Fig. 8.
- Include remove bottom plate screw, then slide out chassis board and disconnect metal shield.

Video panel :

- After remove the metal frame (Fig. 5), to remove the metal shield on rear side of Video panel for measurement.

Main panel :

After remove the metal frame.

- To cut out cable tie and disconnect "video panel"
- To disconnect EHT cable
- To disconnect ground wire(1703) of video board.
- To disconnect M1311(4pin) to control panel.
- To disconnect M1501(4pin) yoke connector.
- To disconnect M1131(2pin) degaussing coil
- To slide out Main panel as Fig. 1.

Service position :

To get service position as Fig. 1 through Fig. 2 to Fig. 8.

2. Repair instructions

After the service position was obtained, all the panel's copper track side could be accessed.



Fig. 2




Fig. 3

Fig. 4




Fig. 5




Fig. 6




Fig. 1 Service Position





Fig. 7



Fig. 8

Wiring Diagram

[Go to cover page](#)



EDID log file

Vendor/Product Identification

ID Manufacturer Name : PHL
 ID Product Code : 0009 (HEX.)
 ID Serial Number : 1E240 (HEX.)
 Week of Manufacture : 8
 Year of Manufacture : 2002

EDID Version, Revision

Version : 1
 Revision : 3

Basic Display Parameters/Features

Video Input Definition : Analog Video Input
 0.700V/0.000V (0.70Vpp)
 without Blank-to-Black Setup
 Separate Sync
 Composite Sync
 without Sync on Green
 no Serration required
 Maximum H Image Size : 40
 Maximum V Image Size : 30

Display Transfer Characteristic : 2.86
 (gamma)

Feature Support (DPMS) : Standby
 Suspend
 Active Off

Display Type : RGB color display
 GTF supported : Based on GTF standard

Color Characteristics

Red X coordinate : 0.642
 Red Y coordinate : 0.322
 Green X coordinate : 0.285
 Green Y coordinate : 0.595
 Blue X coordinate : 0.144
 Blue Y coordinate : 0.061
 White X coordinate : 0.283
 White Y coordinate : 0.297

Established Timings

Established Timings I : 720 x 400 @70Hz (IBM,VGA)
 640 x 480 @60Hz (IBM,VGA)
 640 x 480 @72Hz (VESA)
 640 x 480 @75Hz (VESA)
 800 x 600 @60Hz (VESA)

Established Timings II : 800 x 600 @72Hz (VESA)
 800 x 600 @75Hz (VESA)
 1024 x 768 @60Hz (VESA)
 1024 x 768 @70Hz (VESA)
 1024 x 768 @75Hz (VESA)
 1280 x 1024 @75Hz (VESA)

Manufacturer's timings : 1152 x 870 @75Hz (Apple,Mac II)

Standard Timing Identification #1

Horizontal active pixels : 1024
 Aspect Ratio : 4:3
 Refresh Rate : 85

Standard Timing Identification #2

Horizontal active pixels : 800
 Aspect Ratio : 4:3
 Refresh Rate : 85

Standard Timing Identification #3

Horizontal active pixels : 1280
 Aspect Ratio : 5:4
 Refresh Rate : 75

Standard Timing Identification #4

Horizontal active pixels : 1600
 Aspect Ratio : 4:3
 Refresh Rate : 75

Standard Timing Identification #5

Horizontal active pixels : 1600
 Aspect Ratio : 4:3
 Refresh Rate : 85

Standard Timing Identification #6

Horizontal active pixels : 1792
 Aspect Ratio : 4:3
 Refresh Rate : 75

Standard Timing Identification #7

Horizontal active pixels : 1920
 Aspect Ratio : 4:3
 Refresh Rate : 75

Detailed Timing #1

Pixel Clock (MHz) : 297
 H Active (pixels) : 1920
 H Blanking (pixels) : 720
 V Active (lines) : 1440
 V Blanking (lines) : 60
 H Sync Offset (F Porch) (pixels): 144
 H Sync Pulse Width (pixels) : 224
 V Sync Offset (F Porch) (lines): 1
 V Sync Pulse Width (lines) : 3
 H Image Size (mm) : 392
 V Image Size (mm) : 294
 H Border (pixels) : 0
 V Border (lines) : 0
 Flags : Non-interlaced
 : Normal Display, No stereo
 : Digital Separate sync.
 : Negative Vertical Sync.
 : Negative Horizontal Sync.

Monitor Descriptor #2

Serial Number : TY 123456

Monitor Descriptor #3

Monitor Name : PHILIPS 201B4

Monitor Descriptor #4

Monitor Range Limits
 Min. Vt rate Hz : 50
 Max. Vt rate Hz : 160
 Min. Horiz. rate kHz : 30
 Max. Horiz. rate kHz : 115
 Max. Supported Pixel : 300

No secondary GTF timing formula supported.

Extension Flag

: 0

Check sum

: F8 (HEX.)

EDID data (128 bytes)

0: 00 1: ff 2: ff 3: ff 4: ff 5: ff 6: ff 7: 00
 8: 41 9: 0c 10: 09 11: 00 12: 40 13: e2 14: 01 15: 00
 16: 08 17: 0c 18: 01 19: 03 20: 6c 21: 28 22: 1e 23: ba
 24: e9 25: 61 26: e8 27: a4 28: 52 29: 49 30: 98 31: 24
 32: 0f 33: 48 34: 4c 35: ad 36: cf 37: 80 38: 61 39: 59
 40: 45 41: 59 42: 81 43: 8f 44: a9 45: 4f 46: a9 47: 59
 48: c1 49: 4f 50: d1 51: 4f 52: 01 53: 01 54: 04 55: 74
 56: 80 57: d0 58: 72 59: a0 60: 3c 61: 50 62: 90 63: e0
 64: 13 65: 00 66: 88 67: 26 68: 11 69: 00 70: 00 71: 18
 72: 00 73: 00 74: 00 75: ff 76: 00 77: 20 78: 54 79: 59
 80: 20 81: 20 82: 31 83: 32 84: 33 85: 34 86: 35 87: 36
 88: 0a 89: 20 90: 00 91: 00 92: 00 93: fc 94: 00 95: 50
 96: 48 97: 49 98: 4c 99: 49 100: 50 101: 53 102: 20 103: 32
 104: 30 105: 31 106: 42 107: 34 108: 00 109: 00 110: 00 111: fd
 112: 00 113: 32 114: a0 115: 1e 116: 73 117: 1e 118: 00 119: 0a
 120: 20 121: 20 122: 20 123: 20 124: 20 125: 20 126: 00 127: f8

Go to cover page

1. General

DDC Data Re-programming

In case the main EEPROM with Software DDC which store all factory settings were replaced because a defect, repaired monitor the serial numbers have to be re-programmed.

It is advised to re-soldered the main EEPROM with Software DDC from the old board onto the new board if circuit board have been replaced, in this case the DDC data does not need to be re-programmed.

Additional information

Additional information about DDC (Display Data Channel) may be obtained from Video Electronics Standards Association (VESA). Extended Display Identification Data(EDID) information may be also obtained from VESA.

DDC EDID structure
For the monitor : Standard Version 3.0
Structure Version 1.2

2. System and equipment requirements

- 1. An i486 (or above) personal computer or compatible.
 - 2. Microsoft operation system Windows 95/98.
 - 3. EDID301.EXE program (3138 106 10103) shown as Fig. 1
 - 4. Software DDC Alignment kits (4822 310 11184) shown as Fig. 2.
- The kit contents: a. Alignment box x1
b. Printer cable x1
c. D-Sub cable x1

Note: The EDID301.EXE (Release Version 1.58, 20000818) is a windows-based program, which cannot be run in MS-DOS.




Figure 1 Diskette with EDID301.EXE





Fig. 2 Alignment Kits

3. Pin assignment

A. 15-pin D-Sub Connector

The 15-pin D-sub connector (male) of the signal cable on the 3rd row for DDC feature :



Pin No.	Assignment
1	Red video input
2	Green video input
3	Blue video input
4	Identical output - connected to pin 10
5	Self test
6	Red video ground
7	Green video ground
8	Blue video ground
9	No pin
10	Logic ground
11	Identical output - connected to pin 10
12	Serial data line (SDA)
13	H. Sync / H + V
14	V. Sync (VCLK for DDC)
15	Data clock line (SCL)

4. Configuration and procedure

There is no Hardware DDC (DDC IC) anymore. Main EEPROM stores all factory settings and DDC data (EDID code) which is so called Software DDC. The following section describes the connection and procedure for Software DDC application. The main EEPROM can be re-programmed by enabling "factory memory data write" function on the DDC program (EDID301.EXE).

*** INITIALIZE ALIGNMENT BOX ***

In order to avoid that monitor entering power saving mode due to sync will cut off by alignment box, it is necessary to initialize alignment box before re-programming DDC Data. Following steps show you the procedures and connection.

Step 1: Supply 8~12V DC power source to the Alignment box by plugging a DC power cord or using batteries.

Step 2: Connecting printer cable and video cable of monitor as shown in Fig.3.




Fig. 3

Step 3: Installation of EDID301.EXE

Method 1: Start on DDC program

Start Microsoft Windows.

1. Insert the disk containing EDID301.EXE program into floppy disk drive.
2. Click Start, choose Run at start menu of Windows 95/98 as shown in Fig. 4.




Fig. 4

3. At the submenu, type the letter of your computer's floppy disk drive followed by :EDID301 (for example, A:\EDID301, as shown in Fig. 5).



Fig. 5

4. Click **OK** button. The main menu appears (as shown in Fig. 6). **This is for initialize alignment box.**




Fig. 6

Note 1: If the connection is improper, you will see the following error message (as shown in Fig. 7) before entering the main menu. Meanwhile, the (read EDID) function will be disable. At this time, please make sure all cables are connected correctly and fixedly, and the procedure has been performed properly.



Fig. 7

Method 2: After create a shortcut of EDID301.EXE

- : Double click EDID301 icon (as shown in Fig. 8) which is on the screen of Windows Wallpaper. Bring up main menu of EDID301 as shown in Fig. 9. **This is for initialize alignment box.**



Fig. 8





Fig. 9

Note 2: During the loading, EDID301 will verify the EDID data which just loaded from monitor before proceed any further function, once the data structure of EDID can not be recognized, the following error message will appear on the screen as below. Please confirm following steps to avoid this message.

1. The data structure of EDID was incorrect.
2. DDC IC that you are trying to load data is empty.
3. Wrong communication channel has set at configuration setup windows.
4. Cables loosed or poor contact of connection.




DDC Instructions (Continued)


◀◀ Go to cover page


Re-programming EEPROM (Software DDC)

Step 1: After initialize alignment box, connecting all cables and box as shown in Fig. 10




Step 2: Read DDC data from monitor

- 1-1 Click the left key of Mouse, or hit any key on the keyboard, then the characters disappear from the screen.
- 1-2 Click  icon as shown in Fig. 11 from the tool bar to bring up the "Configuration Setup" windows as shown in Fig. 12.




2. Select the DDC2B as the communication channel. Select "Enable" & fill out "F0" for Mapped EDID page address as shown in Fig. 12.





3. Click OK button to confirm your selection.

4. Click  icon (Read EDID function) to read DDC EDID data from monitor. The EDID codes will display on screen as shown in Fig. 13.




Step 3: Modify DDC data (verify EDID version, week, year)

1. Click  (new function) icon from the tool bar, bring up Step 1 of 9 as shown in Fig. 14. EDID301 DDC application provides the function selection and text change (select & fill out) from Step 1 to Step 9.



Step 4: Modify DDC data (Monitor Serial No.)

1. Click **Next** till the Step 7 of 9 window appears as shown in Fig. 15.
2. Fill out the new Serial No. (for example, TY 503960, TY 123456).
3. Click **Next** till the last step window appears, then click **Finish** to exit the Step window.




Definition of Serial Number (barcode format)

TY 0 0 0 2 1 2 0 0 0 0 0 1

- Serial Number (U.S.A: 8 digit)
(Others regions: 6 digit)
- Week
- Year
- TY Code
TY----Chungli
CX----Dong Guan
HD----Hungary
BZ----Suzhou

Step 5: **Configuration Setup & Enter Factory Mode ** for "write EDID data"

1. Click  icon from the tool bar to bring up the Configuration Setup windows again. Then, select "Software DDC only" as shown in Fig. 16. Click "OK".




Fig. 16

If you do not select "Software DDC only", when you execute "write EDID", it will bring up an error message as below.



To access factory mode

1. Turn off monitor (don't turn off PC)
2. Press "◀▶" and "⏻" simultaneously on the front control panel, then press "⏻", wait till the OSD menu with characters "CM25 PLUS V0.70 20020115 (below OSD menu)" come on the screen of monitor.




Fig. 17



Factory Mode Indicator

If OSD menu disappears on the screen of monitor, press "⏻" again (anytime), then the OSD menu comes on the screen again.

If you do not access "Factory mode", when you execute "write EDID", it will bring up an error message as below.



Step 6: Write DDC data

1. Click  (Write EDID) icon from the tool bar to write DDC data. Bring up "Writing 0%~100%, ready" a progressing bar on the left down corner.
2. Click  (Read EDID) to confirm it.

Step 7: Confirm Serial Number in User Mode


1. Press the ⏻ button to turn off the monitor. Press the ⏻ button again to turn on the monitor.
2. Press the ⏻ button to bring up the OSD Main Menu.
3. Press the ⏻ button to select Extra Controls, press the ⏻ button to confirm your selection.
4. Confirm the Serial Number "123456" is updated as shown in Fig. 18.



Fig. 18

Step 8: Save DDC data

Sometimes, you may need to save DDC data as a text file for using in other IC chip. To save DDC data, follow the steps below:

1. Click  (Save) icon (or click "file" -> "save as") from the tool bar and give a file name as shown in Fig. 19. The file type is EDID301 file (*.ddc) which can be open in WordPad. By using WordPad, the texts of DDC data & table (128 bytes, hex code) can be modified. If DDC TEXTS & HEX Table are completely correct, it can be saved as .ddc file to re-load it into EEPROM for DDC Data application.






Fig. 19

2. Click **Save**.

◀◀ Go to cover page

Step 9: Load DDC data

1. Click  from the tool bar.
2. Select the file you want to open as shown in Fig. 20.
3. Click **Open**.
4. Access "Factory Mode" and enable "Software DDC only" as shown in Fig. 17 & Fig. 16.
5. Write EDID (click ).




Fig. 20

Note 2 : In Factory Mode: Read/Write DDC data

Before Read/Write EDID code, please confirm that the **Software DDC only** was enabled as shown in Fig. 23.




Fig. 23

Step 10: Exit DDC program

Pull down the File menu and select Exit as shown in Fig. 21.
(EDID Tool 3.01)




Fig. 21

Note1 : In User Mode: Read DDC data only

Before read EDID code, please confirm that the **Software DDC only** was disabled as shown in Fig. 22.




Fig. 22

If you do not disable "Software DDC only", when you execute "read EDID", it will bring up an error message as below.



0. General

When carry-out the electrical settings in many cases a video signal must be applied to the monitor. A computer with :

- ATIGPT-1600 (4822 397 10065), Mach 64 (up to 115kHz)

are used as the video signal source. The signal patterns are selected from the "service test software" package, see user guide 4822 727 21046 (GPT-1600).

0.1 This monitor has 34 factory-preset modes as below

31.469 KHz/59.941 Hz, 640 X 480	81.250 KHz/65.000 Hz, 1600 X 1200
31.468 KHz/70.084 Hz, 720 X 400	83.640 KHz/59.999 Hz, 1792 X 1344
37.5 KHz/75 Hz, 640 X 480	86.333 KHz/59.995 Hz, 1856 X 1392
37.861 KHz/72.810 Hz, 640 X 480	87.500 KHz/70.000 Hz, 1600 X 1200
37.879 KHz/60.317 Hz, 800 X 600	90.000 KHz/60.000 Hz, 1920 X 1440
43.269 KHz/85.008 Hz, 640 X 480	91.146 KHz/85.024 Hz, 1280 X 1024
46.875 KHz/75.000 Hz, 800 X 600	93.750 KHz/75.000Hz, 1600 X 1200
48.077 KHz/72.188 Hz, 800 X 600	106.250KHz/85.00 Hz, 1600 X 1200
48.363 KHz/60.004Hz, 1024X 768	106.270KHz/74.997Hz, 1792 X 1344
49.722 KHz/74.546Hz, 832 X 624	112.5KHz/75Hz, 1920 X 1440
50.628 KHz/100.10 Hz, 640 X 480	109.950KHz/75Hz, 1856 X 1392
53.674 KHz/85.061 Hz, 800 X 600	114.048KHz/81Hz, 1792 X 1344
56.476 KHz/70.069 Hz, 1024X 768	115.236KHz/106.7Hz, 1280 X 1024
60.023KHz/75.029Hz, 1024 X 768	115.238KHz/91.758Hz, 1600 X 1200
63.923 KHz/100.00 Hz, 800 X 600	
63.981KHz/60.020Hz, 1280 X 1024	
68.677KHz/84.997Hz, 1024 X 768	
68.681KHz/74.979Hz, 1152 X 870	
75.000KHz/60.000 Hz, 1600 X 1200	
79.976KHz/75.024 Hz, 1280 X 1024	

0.2 With normal VGAcard:

If not using the ATI card during repair or alignment, The service engineer also can use this service test software adapting with normal standard VGA adaptor and using standard VGA mode 640 x 480, 31.5 kHz/60 Hz (only) as signal source.

0.3 AC/DC Measurement:

The measurements for AC waveform and DC figure is based on 640 x 480 31.5 kHz/60 Hz resolution mode with test pattern "gray scale".

Power input: 110V AC

1. B+ supply voltage (3157)210Vdc

- Apply a video signal in the 1024 x 768 with 68.7 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Pre-set trimming potentiometer 3157(B+) and 3698(EHT) in mid-position.
- Set Vg2 (screen) to fully Counter-clockwise (zero beamcurrent).
- Connect a dc voltmeter between the joint of capacitor 2154 and ground (common ground).
- Set the B+ trimming potentiometer 3157 so that the reading on the dc voltmeter is 210 V +/- 0.2 Vdc.

2. High-voltage EHT (3698)

- Apply a video signal in the 1024 x 768 with 68.7 kHz/85Hz mode.
- Select the "cross-hatch" pattern.
- Set the brightness control and the contrast control to the minimum position.
- Turn off the power.

- Connect a "high-voltage voltmeter" between the high-voltage connection of the picture tube and earth.
- Turn on the power.
- Set the EHT trimming potentiometer 3661 so that the "high-voltage voltmeter" reads 27.0 kV +/- 0.2 kV .

- Turn off the power.
- Remove the "high-voltage voltmeter" from the picture tube.
- Turn on the power again.

3. Monitor the following auxiliary voltages.

SOURCE ACROSS C2362	+ 8.0V +/- 0.5 VDC
SOURCE ACROSS C2143	+ 5.0V +/- 0.5 VDC
SOURCE ACROSS C2361	+ 12.0V +/- 0.5 VDC
SOURCE ACROSS C2134	+ 15.0V +/- 1.0 VDC
SOURCE ACROSS C2137	- 15.0V +/- 1.0 VDC
SOURCE ACROSS D6148	+ 6.3V +/- 0.5 VDC
SOURCE ACROSS C2131	+ 210.0V +/- 1.5 VDC
SOURCE ACROSS C2133	+ 82.7V +/- 2.0 VDC

4. General conditions for alignment

- 4.1 During all alignments, supply a distortion free AC mains voltage to set via an isolating transformer with low internal impedance.
- 4.2 Align in pre-warmed condition, at least 30 minutes warm-up with nominal picture brightness.
- 4.3 Purity, geometry and subsequent alignments should be carried out in magnetic cage with correct magnetic field.

Northern hemisphere : H=0, V=450+/-50 mG, Z=0

Southern hemisphere : H=0, V=-450+/-50 mG, Z=0

Equatorial Support : H=0, V=0 mG, Z=0

- 4.4 All voltages are to be measured or applied with respect to ground.

Note: Do not use heatsink as ground.

- 4.5 Adjust function controls " " to center position except for contrast control which should be set to MAX.

5. To access factory mode:

- Turn off monitor (don't turn off PC)
- Press " " and " " simultaneously on the front control panel, then press " ", wait till the OSD menu with characters " factory mode (below OSD menu)" come on the screen of monitor.



- If OSD menu disappears on the screen of monitor, press " " again (anytime), then the OSD menu comes on the screen again.
- using " " : to select OSD menu.
- using " " : to increase or decrease the setting.
- Using " " to confirm the selection.

Go to cover page

7. Alignment of Vg2 cut-off point, white tracking

Equipment : 1. Video Test Generator-801GC (Quantum Data)

2. Color-analyzer (Minolta CA-100)

VG2 [(screen), at the bottom of the L.O.T.].

7.1 Apply a video signal in the 1024 x 768 with 68.7 kHz/85 Hz mode, select the "full white pattern" (size 306 x 230 mm).

* Use color-analyzer (Minolta CA-100) to adjust R/G/B cutoff and Gain.

OSD R/G/B cut-off and R/G/B gain can be accessed (for Philips CRT), with initial data:

9300 °K

R cutoff = 62%, R gain = 71% (f° C)

G cutoff = 62%, G gain = 71% (f° C)

B cutoff = 62%, B gain = 71% (f° C)

6500 °K

R cutoff = 62%, R gain = 71% (f° C)

G cutoff = 62%, G gain = 71% (f° C)

B cutoff = 62%, B gain = 71% (f° C)

5500 °K

R cutoff = 62%, R gain = 71% (f° C)

G cutoff = 62%, G gain = 71% (f° C)

B cutoff = 62%, B gain = 71% (f° C)

Brightness = 50%, Sub-Contrast = 88%, ABL = 58% (I² C)

Step 1: To access factory mode

- Turn off monitor (don't turn off PC)
- Press " " and " " simultaneously on the front control panel, then press " ", wait till the OSD menu with characters CM25 PLUS V0.70 20020115 (below OSD menu) comes on the screen of monitor as shown in Fig. 2.1.




Fig. 2.1

- If OSD menu disappears on the screen of monitor, press " " again (anytime), then the OSD menu comes on the screen again.
- Using " " to select CM25 PLUS V0.70 20020115.
- Press " " button to access/confirm the selection. Bring up the "function adjustment" as shown in Fig. 2.2.
- Press " " or " " button for function selection as shown in Fig. 2.2.
- Press " " button to access/confirm each item selection (The cursor indicator will be changed from yellow colour to red colour.)
- Using " " or " " : to increase or decrease the value.




Fig. 2.2

(for example: 152 is value of "BIAS R")

BIAS R G B : R(red) G(green) B(blue) cutoff

GAIN R G B : R(red) G(green) B(blue) gain

V FOCUS : Vertical Focus

VLIN BAL : Vertical Linearity Balance

USER : Horizontal size range

RASTER H: Horizontal DC (raster) Shift

RASTER V: Vertical DC (raster) Shift

SUB : Zoom range

SUB : Sub Contrast

V OFFSET : Vertical offset

V GAIN : Vertical Gain

ABL : Auto Beam Limit

T CORNER: Corner Correction of TOP

B CORNER: Corner Correction of BOTTOM

D CONVERGENCE

NS PURITY

7.2 Connect the video input, set brightness control at center, and contrast control at maximum

7.3 Set R,G,B bias at 90 for CPT CRT, at 160 for BGDCRT, SDI CRT

R,G,B gain at 180 9300°K, 6500°K & 5500°K
(EEPROM preload value)

ABL at 150 9300°K, 6500°K & 5500°K
(EEPROM preload value)

SUB-CON at 225 (EEPROM preload value)

7.4 Adjust 9300K Color:

Adjust R3517 until raster appears to reach 0.1 FL

With color analyzer CA 100,

set R,G,B cut-off x=0.283, y=0.297, Y=0.10

7.5 Set R,G,B gain Y=40+/- 1FL, x=0.283, y=0.297

7.6 Repeat 7.4, 7.5 until RGB three guns get x=0.283, y=0.297, readings on low Y=0.10+/-0.05FL and high Y=40+/-1FL brightness of 9300.

7.7 Adjust 6500K color:

With color analyzer CA 100,

set R,G,B cut-off x=0.313, y=0.329, Y=0.10FL

7.8 Adjust 5500K color:

With color analyzer CA 100,

set R,G,B cut-off x=0.332, y=0.347, Y=0.10FL

7.9 Apply full white pattern of 9300 mode, adjust ABL to reach

32 +/- 1FL (at 9300 high brightness of R/G/B gain, contrast at 100%)


7.10 Check full white at contrast and brightness at minimum

8. Focus adjustment

Apply a signal of " @ " character. at 64 kHz/60 Hz mode set the brightness to mid-position , contrast to max - position and adjust the focus for optimal sharpness in the area within 2/3 from the screen center.

9. Loading DDC code

The DDC HEX data should be written into the EEPROM (7803) by EDID301.EXE Program(3138 106 10103) and software DDC Alignment kits (4822 310 11184).




10. Purity adjustment

- Make sure the monitor is not exposed to any external magnetic field.
- Produce a full red pattern on the screen, adjust the purity magnet rings on the PCM assy (on CRT) to obtain a complete field of the color red. This is done by moving the two tabs (2-pole) in such a manner that they advance in an opposite direction but at the same time to obtain the same angle between the two tabs, which should be approximately 180 degree.
- Check by full green pattern and full blue pattern again to observe their respective color purity.

4-pole

Beam motion produced by the 4-pole convergence magnet



Beam displacement direction

Magnetic flux lines

11. Static convergence

Introduction


Slight deviation in the static convergence can be corrected by using two permanent pairs of magnets which are fitted around the neck of the CRT. These are the 4-pole magnet and the 6-pole magnet. The 4-pole magnet move the outermost electron beams (R and B) parallel in the opposite direction from the other. The 6-pole magnet moves the outermost electron beam (R, B and G) parallel in the opposite direction from the other. The magnetic field of the above magnets do not affect the center of the CRT neck.

Setting

- Before the static convergence setting can be made, the monitor must be switched on for 30 minutes.
- The focus setting must be made correctly.
- Signal: 640 * 480, 31.5 kHz/60 Hz mode.
- Set the tabs of the 4-pole magnet in the neutral position. This is when the tabs are opposite one another. In this position the magnets do not affect the deflection of the R and B electron beams.
- Set the tabs of the 6-pole magnet in the neutral position. This is when the tabs are opposite one another. In this position the magnets do not affect the deflection of the R, B, and G electron beams.
- First set the 4-pole magnet optimally.
- Then set the 6-pole magnet optimally.
- If the convergence is not now optimal, then adjust to the optimal setting with the 4-pole magnet and then with the 6- Pole magnet again.
- Set the tabs of the 6-pole magnet in the neutral position. This is when the tabs are opposite one another. In this position the magnets do not affect the deflection of the R, B, and G electron beams.
- First set the 4-pole magnet optimally.
- Then set the 6-pole magnet optimally.
- If the convergence is not now optimal, then adjust to the optimal setting with the 4-pole magnet and then with the 6- pole magnet again.

6-pole

Beam motion produced by the 6- pole convergence magnet



Safety test requirements

◀◀ Go to cover page

All units that are returned for service or repair must pass the original manufactures safety tests. Safety testing requires both **Hipot** and **Ground Continuity** testing.

HI-POT TEST INSTRUCTION

1. Application requirements

- 1.1 All mains operated products must pass the Hi-Pot test as described in this instruction.
- 1.2 This test must be performed again after the covers have been refitted following the repair, inspection or modification of the product.

2. Test method

2.1 Connecting conditions

- 2.1.1 The test specified must be applied between the parallel-blade plug of the mainscord and all accessible metal parts of the product.
- 2.1.2 Before carrying out the test, reliable conductive connections must be ensured and thereafter be maintained throughout the test period.
- 2.1.3 The mains switch(es) must be in the "ON" position.

2.2 Test Requirements

All products should be HiPot and Ground Continuity tested as follows:

Condition	HiPot Test for products where the mains input range is Full range(or 220V AC)	HiPot Test for products where the mains input is 110V AC(USA type)	Ground Continuity Test requirement
Test voltage	2820VDC (2000VAC)	1700VDC (1200VAC)	Test current: 25A,AC Test time: 3 seconds(min.) Resistance required: $\leq 0.09 + R$ ohm, R is the resistance of the mains cord.
Test time (min.)	3 seconds	1 second	
Trip current (Tester)	set at 100 uA for Max. limitation; set at 0.1 uA for Min. limitation	5 mA	
Ramp time	set at 2 seconds		

- 2.2.1 The test with AC voltage is only for production purpose, Service center shall use DC voltage.
- 2.2.2 The minimum test duration for Quality Control Inspector must be 1 minute.No breakdown during the test.
- 2.2.3 The test voltage must be maintained within the specified voltage + 5%.
- 2.2.4 The grounding blade or pin of mains plug must be conducted with accessible metal parts.

3. Equipments and Connection


3.1. Equipments

For example :

- ChenHwa 9032 PROGRAMMABLE AUTO SAFETY TESTER
- ChenHwa 510B Digital Grounding Continuity Tester
- ChenHwa 901 (AC Hi-pot test), 902 (AC, DC Hi-pot test) Withstanding Tester

3.2. Connection

- * Turn on the power switch of monitor before Hipot and Ground Continuity testing.



(ChenHwa 9032 tester)

Video cable



Grounding screw




Power outlet


(Rear view of monitor)

4. Recording

Hipot and Ground Continuity testing records have to be kept for a period of 10 years.


FUNCTION BLOCK OF COCA+ 201B4 M25P





Waveform (A)

A1 7701-6




1 V/div AC
10 μ S/div

A3 7705-1




50 V/div AC
5 mS/div

A7 7782-B




0.5 V/div AC
10 μ S/div

A1 7701-8




1 V/div AC
10 μ S/div

A3 7705-5




50 V/div AC
5 mS/div

A1 7701-10




1 V/div AC
10 μ S/div

A4 1710-12




50 V/div AC
10 μ S/div

A2 7705-9




1 V/div AC
10 μ S/div

A4 1710-9




50 V/div AC
10 μ S/div

A2 7705-11




1 V/div AC
10 μ S/div

A4 1710-7




50 V/div AC
10 μ S/div

A2 7705-8




1 V/div AC
10 μ S/div

A5 7781-2




0.5 V/div AC
10 μ S/div

A3 7705-3




50 V/div AC
5 mS/div

A6 7781-5



2 V/div AC
10 μ S/div



GRID BOARD REF LABELSIDE		
1703 A2	B	
1705 B2	B	
1706 B1	B	
1710 A1	B	
1711 A1	B	
1712 B1	B	
2704 A1	B	
2705 A2	B	
2706 A1	B	
2724 A2	B	
2725 A2	B	
2726 A2	B	
2744 A1	B	
2745 B2	B	
2746 A1	B	
2748 A1	B	
2752 A2	B	
2753 A2	B	
2761 B1	B	
2762 B1	B	
2763 B1	B	
2764 B1	B	
2765 A1	B	
2770 B1	B	
2772 B1	B	
2775 B2	B	
2777 B2	B	
2779 B2	B	
2780 B2	B	
2781 B2	B	
2782 B2	B	
2791 A1	B	
2797 B2	B	
2798 A1	B	
2811 A2	B	
3706 A2	B	
3707 A2	B	
3709 A1	B	
3726 A2	B	
3727 A2	B	
3729 A2	B	
3746 B2	B	
3747 B2	B	
3749 A1	B	
3752 A1	B	
3753 A2	B	
3754 A1	B	
3760 A1	B	
3761 B1	B	
3763 B1	B	
3764 B1	B	
3765 B2	B	
5701 A1	B	
5702 A1	B	
5721 A2	B	
5731 A1	B	
5734 A1	B	
5760 B2	B	
5766 B2	B	
5767 A1	B	
5768 B1	B	
5781 A1	B	
5782 A1	B	
5783 A1	B	
5791 A1	B	
6761 B1	B	
6762 B2	B	
7701 A1	B	
7705 A1	B	
7706 A2	B	
7707 A2	B	
7726 A2	B	
7727 A2	B	

7746 B2	B
7747 B2	B
7781 A1	B
7801 B1	B
7802 B1	B
7803 A2	B
7804 A1	B
7805 A2	B
7806 B1	B
7808 A2	B
7809 A1	B
7810 A1	B
8701 A1	B

GRID BOARD REF LABELSIDE		
1703 B6	B	
1705 B5	B	
1706 A5	B	
1710 B6	B	
1711 B6	B	
1712 A5	B	
2704 B6	B	
2705 C7	B	
2706 B6	B	
2724 B7	B	
2725 C6	B	
2726 B6	B	
2744 B7	B	
2745 C6	B	
2746 A6	B	
2748 A7	B	
2752 B7	B	
2753 B7	B	
2761 A6	B	
2762 A6	B	
2763 B5	B	
2764 A6	B	
2765 A6	B	
2770 B5	B	
2772 B5	B	
2775 B5	B	
2777 B5	B	
2779 C5	B	
2780 C5	B	
2781 C5	B	
2782 B5	B	
2791 A6	B	
2797 C5	B	
2798 A6	B	
2811 C7	B	
3706 C7	B	
3707 C7	B	
3709 B6	B	
3726 C6	B	
3727 C6	B	
3729 B6	B	
3746 C6	B	
3747 C6	B	
3749 A6	B	
3752 B7	B	
3753 B7	B	
3754 B7	B	
3760 A6	B	
3761 A6	B	
3763 B5	B	
3764 A6	B	
3765 B5	B	
5701 A7	B	
5702 B7	B	
5721 B7	B	
5731 B7	B	
5734 A7	B	
5760 C6	B	
5766 C5	B	
5767 A6	B	
5768 B6	B	
5781 A6	B	
5782 A6	B	
5783 A6	B	
5791 A6	B	
6761 B5	B	
6762 B5	B	
7701 A7	B	
7705 B7	B	
7706 C7	B	
7707 C7	B	
7726 C6	B	

7727 C6	B
7746 C6	B
7747 C6	B
7781 A6	B
7801 A5	B
7802 A6	B
7803 B6	B
7804 B6	B
7805 B6	B
7806 A6	B
7808 B6	B
7809 B7	B
7810 A6	B
8701 A7	B

GRID BOARD REF LABELSIDE		
2701 A1	A	
2702 A1	A	
2707 A1	A	
2708 A1	A	
2709 A1	A	
2710 A2	A	
2720 A2	A	
2721 A1	A	
2722 A1	A	
2727 A1	A	
2736 A1	A	
2740 A1	A	
2741 A1	A	
2742 A1	A	
2747 A1	A	
2749 A1	A	
2750 A1	A	
2751 A2	A	
2756 A1	A	
2757 A1	A	
2760 A1	A	
2766 A1	A	
2767 A1	A	
2768 A1	A	
2771 B2	A	
2773 B2	A	
2774 B2	A	
2776 B2	A	
2778 B2	A	
2783 B1	A	
2784 B1	A	
2785 B1	A	
2786 B1	A	
2787 B1	A	
2788 B1	A	
2789 B1	A	
2790 B1	A	
2792 A1	A	
2793 A1	A	
2794 A1	A	
2795 A1	A	
2796 A1	A	
2799 A1	A	
2801 B1	A	
2802 B1	A	
2803 B1	A	
2804 B1	A	
2805 B1	A	
2806 B1	A	
2807 B1	A	
2812 A1	A	
2813 A2	A	
2814 B1	A	
2815 B1	A	
2821 A1	A	
2822 A1	A	
2831 A2	A	
2832 A2	A	
3701 A1	A	
3702 A1	A	
3703 A1	A	
3704 A2	A	
3705 A1	A	
3708 A2	A	
3710 A2	A	
3711 A2	A	
3712 A1	A	
3713 A1	A	
3714 A1	A	
3715 A1	A	
3716 A1	A	
3717 A1	A	

3718 A1	A
3719 A2	A
3720 A2	A
3721 A1	A
3722 A1	A
3723 A1	A
3724 A2	A
3725 A2	A
3728 A2	A
3730 A2	A
3731 A2	A
3732 A1	A
3733 A1	A
3734 A1	A
3735 A1	A
3736 A1	A
3737 A1	A
3738 A2	A
3739 A2	A
3740 A2	A
3741 A1	A
3742 A1	A
3743 A1	A
3744 A1	A
3745 A1	A
3748 B2	A
3750 B2	A
3751 B2	A
3755 A1	A
3758 B2	A
3759 B2	A
3762 A1	A
3766 B1	A
3767 B1	A
3768 B1	A
3769 B1	A
3781 A1	A
3782 A1	A
3783 A1	A
3784 A1	A
3785 A1	A
3786 A1	A
3787 A1	A
3788 A1	A
3789 A1	A
3790 A1	A
3791 A1	A
3792 A1	A
3801 B1	A
3802 B1	A
3803 B1	A
3804 B1	A
3805 B1	A
3806 B1	A
3807 B1	A
3808 B1	A
3809 B1	A
3811 A2	A
3812 A1	A
3813 A1	A
3814 A2	A
3815 A2	A
3816 B1	A
3821 A1	A
3822 A1	A
3823 A1	A
3824 A1	A
3825 A1	A
3831 A2	A
3832 A2	A
3833 A2	A
3834 A2	A
3835 A2	A
3836 B1	A
3841 B1	A


3842 B1	A
3843 B1	A
3844 B1	A
3845 B1	A
3846 B1	A
5703 A2	A
5704 A1	A
5722 A2	A
5732 B2	A
5733 B2	A
5735 A1	A
5736 A1	A
5737 A2	A
5761 B1	A
5762 B2	A
5763 B2	A
5764 B2	A
5765 B2	A
5801 A1	A
6701 A1	A
6702 A1	A
6703 A2	A
6704 A2	A
6705 A2	A
6721 A2	A
6722 A2	A
6723 A2	A
6724 A2	A
6725 A2	A
6726 A1	A
6731 A1	A
6732 A1	A
6741 A1	A
6742 A1	A
6743 A1	A
6744 B2	A
6745 B2	A
6763 B1	A
6764 B1	A
6801 B1	A
6802 B1	A
6803 A1	A
6811 A2	A
6812 A2	A
6813 A1	A
6821 A1	A
6822 A1	A
6823 A1	A
6831 A2	A
6832 A2	A
6833 B1	A
7782 A1	A
7783 A1	A
7807 B1	A

GRID BOARD REF LABELSIDE		
2701 A7	A	
2702 A7	A	
2707 A7	A	
2708 A7	A	
2709 A7	A	
2710 B7	A	
2720 B7	A	
2721 A7	A	
2722 A7	A	
2727 A7	A	
2736 A6	A	
2740 B7	A	
2741 A7	A	
2742 A7	A	
2747 A7	A	
2749 B7	A	
2750 B7	A	
2751 B7	A	
2756 A7	A	
2757 A7	A	
2760 B6	A	
2766 A6	A	
2767 A6	A	
2768 A7	A	
2771 B5	A	
2773 B5	A	
2774 B5	A	
2776 B5	A	
2778 B5	A	
2783 A5	A	
2784 A5	A	
2785 A5	A	
2786 A5	A	
2787 A5	A	
2788 B5	A	
2789 B5	A	
2790 B5	A	
2792 A7	A	
2793 A7	A	
2794 A6	A	
2795 A6	A	
2796 A6	A	
2799 A6	A	
2801 A5	A	
2802 A5	A	
2803 A5	A	
2804 A6	A	
2805 A5	A	
2806 A5	A	
2807 A6	A	
2812 B6	A	
2813 B6	A	
2814 A6	A	
2815 A6	A	
2821 A7	A	
2822 B6	A	
2831 B6	A	
2832 C6	A	
3701 A7	A	
3702 A7	A	
3703 B7	A	
3704 B7	A	
3705 B7	A	
3708 C7	A	
3710 C7	A	
3711 C7	A	
3712 A7	A	
3713 A7	A	
3714 A7	A	
3715 A7	A	
3716 A7	A	
3717 A7	A	

3719	C7	A	3844	A6	A
3720	C7	A	3845	A6	A
3721	A7	A	3846	A6	A
3722	A7	A	5703	C7	A
3723	B7	A	5704	A6	A
3724	B7	A	5722	C6	A
3725	B7	A	5732	C6	A
3728	B6	A	5733	B5	A
3730	C6	A	5735	B7	A
3731	C6	A	5736	B7	A
3732	A7	A	5737	B7	A
3733	A7	A	5761	B5	A
3734	A7	A	5762	B5	A
3735	A7	A	5763	B5	A
3736	A7	A	5764	B5	A
3737	B7	A	5765	C5	A
3738	B7	A	5801	B7	A
3739	C6	A	6701	B7	A
3740	C6	A	6702	B7	A
3741	A7	A	6703	B7	A
3742	A7	A	6704	C7	A
3743	B7	A	6705	C7	A
3744	A7	A	6721	B7	A
3745	B7	A	6722	B7	A
3748	B6	A	6723	C6	A
3750	C5	A	6724	C6	A
3751	C6	A	6725	B6	A
3755	A7	A	6726	A7	A
3758	C6	A	6731	A7	A
3759	C5	A	6732	A7	A
3762	A6	A	6741	A7	A
3766	A5	A	6742	A7	A
3767	A5	A	6743	B6	A
3768	A5	A	6744	C6	A
3769	B5	A	6745	B6	A
3781	A6	A	6763	A5	A
3782	A6	A	6764	A5	A
3783	A6	A	6801	A5	A
3784	A6	A	6802	A6	A
3785	A6	A	6803	A6	A
3786	A7	A	6811	B7	A
3787	A6	A	6812	B6	A
3788	A7	A	6813	A6	A
3789	A7	A	6821	A7	A
3790	A6	A	6822	B7	A
3791	A7	A	6823	A6	A
3792	A7	A	6831	C7	A
3801	A5	A	6832	C6	A
3802	A5	A	6833	A6	A
3803	A5	A	7782	A7	A
3804	A5	A	7783	A7	A
3805	A6	A	7807	A6	A
3806	A6	A			
3807	A5	A			
3808	A5	A			
3809	A5	A			
3811	B7	A			
3812	B6	A			
3813	B6	A			
3814	B6	A			
3815	B6	A			
3816	A6	A			
3821	A6	A			
3822	A7	A			
3823	A6	A			
3824	B6	A			
3825	A6	A			
3831	B7	A			
3832	B6	A			
3833	B6	A			
3834	C6	A			
3835	B6	A			
3836	A6	A			
3841	A6	A			
3842	A6	A			
3843	A6	A			

Terminal Schematic Diagram


Go to cover page



















































PCB (A1)

1001 A2	F039 F3
1002 B2	F040 G3
1003 C11	F041 G2
1004 B2	F042 D2
1005 C2	F043 G2
1006 D11	F045 F2
1007 C2	F060 F2
1008 E2	F061 B11


GRID BOARD			GRID BOARD		
REF	LABEL	SIDE	REF	LABEL	SIDE
2006	A2	A	1001	A1	B
2008	A1	A	1002	A1	B
2009	A2	A	1003	A2	B
2010	A1	A	1004	A2	B
2012	A1	A	1005	A2	B
2014	A2	A	1006	A1	B
2015	A2	A	1007	A1	B
2016	A2	A	1008	A2	B
2017	A2	A	2001	A1	B
2018	A1	A	2002	A1	B
2019	A1	A	2003	A2	B
2020	A1	A	2004	A2	B
2021	A1	A	2005	A1	B
2031	A1	A	2007	A2	B
2032	A1	A	2011	A1	B
2033	A1	A	2013	A2	B
2034	A1	A	2023	A2	B
2035	A1	A	2025	A2	B
2036	A1	A	2027	A2	B
3001	A1	A	4001	A2	B
3004	A1	A	5001	A1	B
3006	A2	A	5002	A2	B
3007	A2	A	5003	A2	B
3008	A2	A			
3009	A2	A			
3010	A1	A			
3011	A1	A			
3012	A1	A			
3013	A1	A			
3014	A1	A			
3015	A1	A			
3016	A2	A			
3017	A2	A			
3018	A2	A			
3019	A2	A			
3020	A2	A			
3021	A2	A			
3022	A2	A			
3023	A2	A			
6001	A2	A			
6002	A2	A			
6003	A1	A			
6004	A2	A			
6005	A2	A			
6006	A2	A			






B1 7404-142 V/div AC
5 mS/div**B8 7421-17**0.5 V/div AC
5 mS/div**B15 7422-E**5 V/div AC
5 uS/div**B22 7502-B**5 V/div AC
5 uS/div**B30 7543-B**100 V/div AC
5 uS/div**B38 7301-33**2 V/div AC
5 mS/div**B47 7672-D**100 V/div AC
5 uS/div**B2 7404-13**2 V/div AC
5 mS/div**B9 7421-24**2 V/div AC
5 mS/div**B16 7566-B**10 V/div AC
5 mS/div**B23 7502-C**100 V/div AC
5 uS/div**B31 5601-4**100 V/div AC
5 mS/div**B39 7301-34**0.1 V/div AC
5 mS/div**B48 5671-9**100 V/div AC
5 uS/div**B3 7404-12**2 V/div AC
5 mS/div**B10 7421-11**1 V/div AC
5 mS/div**B17 7567-6**10 V/div AC
5 mS/div**B24 5503-5**50 V/div AC
5 uS/div**B32 7622-11**20 V/div AC
5 uS/div**B42 7651-2**0.5 V/div AC
5 uS/div**B49 567-3**100 V/div AC
5 uS/div**B4 7404-15**0.2 V/div AC
10 uS/div**B11 7421-12**0.5 V/div AC
2 mS/div**B18 7567-3**10 V/div AC
5 mS/div**B25 7461-C**5 V/div AC
5 mS/div**B34 7301-8**2 V/div AC
50 uS/div**B43 7651-1**2 V/div AC
5 uS/div**B50 5671-1**100 V/div AC
5 uS/div**B5 7404-1**0.2 V/div AC
10 uS/div**B12 7421-32**5 V/div AC
5 mS/div**B19 7567-5**20 V/div AC
5 mS/div**B27 7425-E**5 V/div AC
5 uS/div**B35 7301-9**2 V/div AC
50 uS/div**B44 7651-10**5 V/div AC
5 uS/div**B51 5671-12**100 V/div AC
5 uS/div**B6 7404-2**0.2 V/div AC
10 uS/div**B13 7421-29**2 V/div AC
5 uS/div**B20 7567-4**5 V/div AC
5 mS/div**B28 7541-D**100 V/div AC
5 uS/div**B36 7301-40**2 V/div AC
10 uS/div**B45 7671-G**5 V/div AC
5 uS/div**B7 7421-16**2 V/div AC
5 uS/div**B14 7422-B**5 V/div AC
5 uS/div**B21 5501-5**50 V/div AC
5 uS/div**B29 7543-C**100 V/div AC
5 uS/div**B37 7301-39**2 V/div AC
5 uS/div**B46 7671-D**5 V/div AC
5 uS/div

Go to cover page




[Go to cover page](#)




Go to cover page

C1 5130-1




10 V/div AC
2 uS/div

C8 5130-12




10 V/div AC
5 mS/div

C2 5130-3




5 V/div AC
2 uS/div

C11 7130-4




5 V/div AC
5 mS/div

C3 5130-5




0.5 V/div AC
2 uS/div

C12 7130-3




5 V/div AC
5 mS/div

C4 5130-7




0.5 V/div AC
2 uS/div

C5 5130-9




0.2 V/div AC
2 uS/div

C6 5130-18




5 V/div AC
5 mS/div


C7 5130-15



10 V/div AC
5 mS/div



MHR Panel PCB (F)



Key Control Schematic Digram


Control Panel PCB (D)

D

PHILIPS



ALL RIGHTS ARE RESERVED. REPRODUCTION IN WHOLE OR IN PART IS PROHIBITED WITHOUT THE WRITTEN CONSENT OF THE COPYRIGHT OWNER.



- 1891 C2
- 1892 C3
- 1893 C3
- 1894 C4
- 1895 C4
- 2891 B2
- 3891 B2
- 3892 B3
- 3893 B3
- 3894 B4
- 3895 B4
- 5891 B2
- 8891 B1
- F894 C1
- F895 C1
- F896 C1
- F897 C1
- F898 C1
- F899 C1

NOTES:
© STAND FOR CHIP COMPONENTS.

CN: TYT 12-

CLASS NO.

KEY CONTROL

CM25+ 201B 40/00C

3138 178 60861

02-01-23

3

NAME Steve Lin/MC Chang

SUPERS

1

10

130

- 1

A4





CHECK

DATE

02-01-23

©

Philips Electronics N.V.



#	GRID	BOARD	
#	REF	LABEL	SIDE
#			
1891	A2	B	
1892	A2	B	
1893	A2	B	
1894	A3	B	
1895	A4	B	
3891	A2	B	
3892	A3	B	
3893	A2	B	
3894	A3	B	
3895	A3	B	
6891	A1	B	
8891	A4	B	

#	GRID	BOARD	
#	REF	LABEL	SIDE
#			
1891	A4	B	
1892	A4	B	
1893	A4	B	
1894	A4	B	
1895	A5	B	
3891	A4	B	
3892	A4	B	
3893	A4	B	
3894	A4	B	
3895	A5	B	
6891	A3	B	
8891	A5	B	

#	GRID	BOARD	
#	REF	LABEL	SIDE
#			
2891	A4	A	
2892	A4	A	
2893	A4	A	
2894	A4	A	
2895	A4	A	
5891	A4	A	
7891	A4	A	

0. Warning

All ICs and many other semi-conductors are susceptible to electrostatic discharges (ESD). Careless handling during repair can reduce life drastically. When repairing, make sure that you are connected with the same potential as the mass of the unit via a wrist wrap with resistance. Keep components and tools also at the same potential !

1. Servicing of SMDs (Surface Mounted Devices)


1.1 General cautions on handling and storage

- Oxidation on the terminals of SMDs results in poor soldering. Do not handle SMDs with bare hands.
- Avoid using storage places that are sensitive to oxidation such as places with sulphur or chlorine gas, direct sunlight, high temperatures or a high degree of humidity. The capacitance or resistance value of the SMDs may be affected by this.
- Rough handling of circuit boards containing SMDs may cause damage to the components as well as the circuit boards. Circuit boards containing SMDs should never be bent or flexed. Different circuit board materials expand and contract at different rates when heated or cooled and the components and/or solder connections may be damaged due to the stress. Never rub or scrape chip components as this may cause the value of the component to change. Similarly, do not slide the circuit board across any surface.

1.2 Removal of SMDs

- Heat the solder (for 2-3 seconds) at each terminal of the chip. By means of litz wire and a slight horizontal force, small components can be removed with the soldering iron. They can also be removed with a solder sucker (see Fig. 1A)

Fig. 1 DISMOUNTING



- While holding the SMD with a pair of tweezers, take it off gently using the soldering iron's heat applied to each terminal (see Fig. 1 B).
- Remove the excess solder on the solder lands by means of litz wire or a solder sucker (see Fig. 1C).


1.3 Caution on removal

- When handling the soldering iron, use suitable pressure and be careful.
- When removing the chip, do not use undue force with the pair of tweezers.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
- The chip, once removed, must never be reused.

1.4 Attachment of SMDs

- Locate the SMD on the solder lands by means of tweezers and solder the component on one side. Ensure that the component is positioned correctly on the solder lands (see Fig. 2A).
- Next complete the soldering of the terminals of the component (see Fig. 2B).


Fig. 2 MOUNTING




2. Caution when attaching SMDs

- When soldering the SMD terminals, do not touch them directly with the soldering iron. The soldering should be done as quickly as possible, care must be taken to avoid damage to the terminals of the SMDs themselves.
- Keep the SMD's body in contact with the printed board when soldering.
- The soldering iron to be used (approx. 30 W) should preferably be equipped with a thermal control (soldering temperature: 225 to 250 °C).
- Soldering should not be done outside the solder land.
- Soldering flux (of rosin) may be used, but should not be acidic.
- After soldering, let the SMD cool down gradually at room temperature.
- The quantity of solder must be proportional to the size of the solder land. If the quantity is too great, the SMD might crack or the solder lands might be torn loose from the printed board (see Fig. 3).

Fig. 3 Examples



Exploded View



Recommended Parts List

201P4 M25P

37

Go to cover page

Model : 201B40/00C

ITEM CODE NUMBER				DESCRIPTION
1	3138	127	52441	FRONT CABINET ASSY(201B4)
2	3138	107	98472	BACK COVER ASSY(201B4)
3	3138	107	98481	PEDESTAL ASSY
4	3138	107	98512	KNOB ASSY
44	3138	104	49471	BASE
46	3138	104	49651	KNOB-OSD
47	3138	104	55631	KNOB-POWER
48	3138	104	50672	LENS-POWER
49	3138	104	49451	SCREW COVER
53	3138	104	49462	SWIVEL
601	3138	117	03881	E-D.F.U. ASSY
450	3138	106	61151	CARTON
451	3138	106	56411	CUSHION - TOP FRONT
452	3138	106	56422	CUSHION - BOTTOM
454	3138	106	45301	P.E. BAG
1053	3138	070	98118	MAINS CORD(220V)-1.5M
1054	3138	188	73461	I/F CABLE
1103	3138	086	00208	FUSE T4AH 250V
1265	3138	178	59931	EEPROM IC ASSY(7336)
5671	3138	188	73701	TFM L.O.T. LAYER 12MM WIRE
7001	9322	142	60682	IC AN5870K 30P
7121	9322	140	39680	IC STRF6456 (LF1352)
7130	9322	140	14667	PHOTOCOUPLER TCET1103G 4P
7143	9322	092	00687	IC L4940V5 3P
7155	9322	083	67676	IC TL431CZ
7301	8238	274	43451	CPU 96148-K420PH-50A)
7363	9334	006	10682	IC MC7812CT 3P
7364	9339	208	10682	IC L7808CV 3P
7404	9332	826	60652	IC HEF4053BP 16P
7421	9352	674	52112	IC TDA4856/V3
7541	9322	180	90687	TRANS IRF730B
7567	9319	002	34682	IC STV9379 7P
7651	9322	121	52682	IC L4990A 16P
7672	9322	146	46687	FET POWIRF740A
7673	9322	134	98687	FET POWF75UM-16A
7701	9352	640	61112	IC TDA4887PS/V1
7781	9322	092	65685	IC WT6803-N160PH-06AB
7801	9322	163	09682	IC WT62P2
7806	9337	060	60112	IC PCF8574P

Model : 201B40/74

ITEM CODE NUMBER				DESCRIPTION
450	3138	106	61361	CARTON
1053	3138	118	76421	MAINS CORD(120V)

Remark: Item 450 and item 1053 are the differences between 201B40/00 and 201B40/74.

Spare Parts List

Go to cover page

Parts List								
CTV : 201B40/00C								
0001	313812752441	FRONT CABINET ASSY-201B4	2131	202203100082	ELCAP KM 250VS 1U PM20	2613	203803513504	ELCAP RGA 50V S 4U7 PM20
0002	313810798472	BACK COVER ASSY	2133	202203100067	ELCAP GL 1VS 220U PM20	2621	222234741473	CAP POL 347250V S 47N PM10
0003	313810798481	PEDESTAL ASSY	2134	202203100065	ELCAP RXJ 25VS 22U PM20	2622	203830100195	CAP PP PPN250V S 120N PM5
0004	313810798512	KNOB ASSY	2135	202203100064	ELCAP RXJ 25VS 10U PM20	2623	203830100165	CAP PP PPN250V S 180N PM5
0041	313810449411	FRONT CABINET	2137	202203100064	ELCAP RXJ 25VS 10U PM20	2624	203830100303	CAP MPP MPS250V S 470N PM5
0042	313810449422	BACK COVER	2139	203803500056	ELCAP SX 16VS 22U PM20	2625	203830100222	CAP MPP MPS250V S 820N PM5
0043	313810449441	REAR-COVER	2143	203803135221	ELCAP VT 16VS 220U PM20	2628	223891015649	CER2 0805 X7R 25V 1N PM10
0044	313810449471	BASE	2154	223886115101	CER1 0805 NP0 50V 1P PM5	2636	203830100402	CAP MPP MPS250V S 1U8 PM5
0046	313810449651	KNOB-OSD	2155	222291019856	CER2 0805 Y5V 25V 330N P8020	2651	203801750221	ELCAP RE 50VS 1U PM20
0047	313810455631	KNOB-POWER	2160	203803452101	ELCAP VX 10VS 1U PM20	2652	223858016616	CER2 0805 X7R 50V 1N5 PM10
0048	313810450672	LENS-POWER	2162	203801750221	ELCAP RE 50VS 1U PM20	2653	223858016621	CER2 0805 X7R 50V 3N3 PM10
0049	313810449451	SCREW COVER	2163	203803511222	ELCAP REA 16V S 470U PM20	2655	203830150151	CAP PP PPN1V S 10N PM2
0053	313810449462	SWIVEL	2171	223858015641	CER2 0805 X7R 50V 22N PM10	2656	203803513309	ELCAP RGA 25V S 220U PM20
1051	2932216247682	CRT M51QBN291X115(SMG)	2172	222236585103	CAP MPOL 1VS 10N PM10	2657	223858016615	CER2 0805 X7R 50V 1N2 PM10
			2173	203803513501	ELCAP RGA 50V S 10U PM20	2658	222278019867	CER2 0805 Y5V 16V 2U2 P8020
			2174	222236525104	CAP MPOL 1VS 1N PM10	2659	203801750285	ELCAP REA 25V S 47U PM20
			2301	203801750222	ELCAP RE 50VS 2U2 PM20	2660	223878019858	CER2 0805 Y5V 16V 470N P8020
			2302	203801750222	ELCAP RE 50VS 2U2 PM20	2661	223878019858	CER2 0805 Y5V 16V 470N P8020
			2303	222236526104	CAP MPOL 1VS 1N PM5	2662	223886115101	CER1 0805 NP0 50V 1P PM5
			2304	203801750218	ELCAP RE 16VS 47U PM20	2663	222278019867	CER2 0805 Y5V 16V 2U2 P8020
			2305	203803511222	ELCAP REA 16V S 470U PM20	2671	203803513901	ELCAP RGA 250V S 33U PM20
			2306	203801750224	ELCAP MM 50VS 10U PM20	2672	223891015649	CER2 0805 X7R 25V 1N PM10
			2307	223886115229	CER1 0805 NP0 50V 22P PM5	2673	202055890562	CERHDT RR 2KVS 330P PM10
			2308	203801750222	ELCAP RE 50VS 2U2 PM20	2681	223858016618	CER2 0805 X7R 50V 2N2 PM10
			2309	203801750222	ELCAP RE 50VS 2U2 PM20	2682	202203100086	ELCAP KL 250VS 1U PM20
			2310	222236525473	CAP MPOL 1VS 47N PM10	2683	203830100174	CAP PP PPN630V S 4N7 PM5
			2311	222236525473	CAP MPOL 1VS 47N PM10	2684	222234741473	CAP POL 347250V S 47N PM10
			2312	225250508205	CER1 DC NP0 50V S 22PPM5	2685	203801750218	ELCAP RE 16VS 47U PM20
			2313	225250508205	CER1 DC NP0 50V S 22PPM5	2686	202055890557	CERHDT RR 1KVS 1N PM10
			2314	223886115229	CER1 0805 NP0 50V 22P PM5	2691	222234741473	CAP POL 347250V S 47N PM10
			2315	223858015636	CER2 0805 X7R 50V 10N PM10	2693	203830200226	CAP MPOL 1VS 1U8 PM5
			2316	222236525473	CAP MPOL 1VS 47N PM10	2694	222236526104	CAP MPOL 1VS 1N PM5
			2336	222236525104	CAP MPOL 1VS 1N PM10			
			2337	223886115229	CER1 0805 NP0 50V 22P PM5			
			2338	223886115229	CER1 0805 NP0 50V 22P PM5			
			2361	203803513204	ELCAP RGA 16V S 330U PM20			
			2362	203803513201	ELCAP RGA 16V S 1U PM20			
			2391	223891015649	CER2 0805 X7R 25V 1N PM10			
			2392	223886115101	CER1 0805 NP0 50V 1P PM5			
			2401	222236525104	CAP MPOL 1VS 1N PM10			
			2421	222236525104	CAP MPOL 1VS 1N PM10			
			2422	222236525154	CAP MPOL 1VS 150N PM10			
			2423	225250508215	CER1 DC NP0 50V S 220PPM5			
			2424	223891015649	CER2 0805 X7R 25V 1N PM10			
			2425	202203100097	ELCAP KM 16VS 15U PM20			
			2426	225250508205	CER1 DC NP0 50V S 22PPM5			
			2431	222236526104	CAP MPOL 1VS 1N PM5			
			2432	203830150186	CAP PP PPN1V S 8N2 PM5			
			2433	203830250218	CAP MPOL 1VS 10N PM2			
			2434	203830150157	CAP PP PPN1V S 5N6 PM2			
			2435	203830150186	CAP PP PPN1V S 8N2 PM5			
			2441	203830150191	CAP PP PPN1V S 3N3 PM2			
			2442	223858016621	CER2 0805 X7R 50V 3N3 PM10			
			2443	223891015645	CER2 0805 X7R 25V 47N PM10			
			2445	203801750218	ELCAP RE 16VS 47U PM20			
			2446	222236525474	CAP MPOL 1VS 470N PM10			
			2456	203801750218	ELCAP RE 16VS 47U PM20			
			2461	203830100104	CAP PP PPN250V S 220N PM5			
			2462	223886115221	CER1 0805 NP0 50V 220P PM5			
			2463	203801750218	ELCAP RE 16VS 47U PM20			
			2464	223858016624	CER2 0805 X7R 50V 5N6 PM10			
			2491	222236525104	CAP MPOL 1VS 1N PM10			
			2501	203803522802	ELCAP BP NK160V S 0U47 PM20			
			2502	203803522801	ELCAP BP NK160V S 1U PM20			
			2503	222236525104	CAP MPOL 1VS 1N PM10			
			2504	222237590559	CAP PP-MPOL 2K5VS 4N3 PM5			
			2506	202055890561	CERHDT RR 2KVS 220P PM10			
			2507	202055890561	CERHDT RR 2KVS 220P PM10			
			2515	202055890557	CERHDT RR 1KVS 1N PM10			
			2516	222236525474	CAP MPOL 1VS 470N PM10			
			2518	222236525104	CAP MPOL 1VS 1N PM10			
			2519	222236525104	CAP MPOL 1VS 1N PM10			
			2520	222236525104	CAP MPOL 1VS 1N PM10			
			2541	202203600002	ELCAP BP NK 50V S 1U PM20			
			2542	203830100117	CAP MPP 1VS 1U PM5			
			2543	202203100082	ELCAP KM 250VS 1U PM20			
			2544	202055890562	CERHDT RR 2KVS 330P PM10			
			2545	223891015649	CER2 0805 X7R 25V 1N PM10			
			2546	223891015649	CER2 0805 X7R 25V 1N PM10			
			2551	203803513301	ELCAP RGA 25V S 47U PM20			
			2552	203803513301	ELCAP RGA 25V S 47U PM20			
			2553	203830100194	CAP PP PPN250V S 1N PM5			
			2554	203830100411	CAP PP PPN250V S 120N PM5			
			2555	222236525104	CAP MPOL 1VS 1N PM10			
			2556	223891015649	CER2 0805 X7R 25V 1N PM10			
			2566	203803513501	ELCAP RGA 50V S 10U PM20			
			2567	203803513305	ELCAP RGA 25V S 470U PM20			
			2568	203803511402	ELCAP REA 35V S 1U PM20			
			2569	225250508215	CER1 DC NP0 50V S 220PPM5			
			2576	222236585223	CAP MPOL 1VS 22N PM10			
			2577	203803513305	ELCAP RGA 25V S 470U PM20			
			2578	222236525104	CAP MPOL 1VS 1N PM10			
			2579	222236525474	CAP MPOL 1VS 470N PM10			
			2586	222236526104	CAP MPOL 1VS 1N PM5			
			2588	222236525104	CAP MPOL 1VS 1N PM10			
			2589	222236525104	CAP MPOL 1VS 1N PM10			
			2602	22527124166	CERHDT F-Y5R 2KVS 180P			
			2603	202055890557	CERHDT RR 1KVS 1N PM10			
			2608	223555900099	CER2 DC 2KVS 10N PM20			

Spare Parts List (Continued)

210B4 M25P 39

Go to cover page

3337 213810113222 RST CRB CFR-12 A 2K2 PM5
3338 213810113222 RST CRB CFR-12 A 2K2 PM5
3340 213810113101 RST CRB CFR-12 A 1R PM5
3341 213810113103 RST CRB CFR-12 A 10K PM5
3342 231291513303 RST MFLM MBB0207A 33K PM1
3343 213810113101 RST CRB CFR-12 A 1R PM5
3344 213810113101 RST CRB CFR-12 A 1R PM5
3345 213810113101 RST CRB CFR-12 A 1R PM5
3347 19802154720 RST SM 0805 4K7 PM5 COL
3348 213810113223 RST CRB CFR-12 A 22K PM5
3349 213810113223 RST CRB CFR-12 A 22K PM5
3350 213810113223 RST CRB CFR-12 A 22K PM5
3361 19802190020 RST SM 0805 JUMP. 0R05 COL
3362 19802190020 RST SM 0805 JUMP. 0R05 COL
3363 19802190020 RST SM 0805 JUMP. 0R05 COL
3365 19802190020 RST SM 0805 JUMP. 0R05 COL
3366 19802190020 RST SM 0805 JUMP. 0R05 COL
3367 19802190020 RST SM 0805 JUMP. 0R05 COL
3393 19802154720 RST SM 0805 4K7 PM5 COL
3394 19802151030 RST SM 0805 10K PM5 COL
3395 19802154720 RST SM 0805 4K7 PM5 COL
3396 19802151030 RST SM 0805 10K PM5 COL
3397 213810113472 RST CRB CFR-12 A 4K7 PM5
3398 213810113101 RST CRB CFR-12 A 1R PM5
3403 19802190020 RST SM 0805 JUMP. 0R05 COL
3404 213810113471 RST CRB CFR-12 A 470R PM5
3421 231291512203 RST MFLM MBB0207A 22K PM1
3422 213810113471 RST CRB CFR-12 A 470R PM5
3423 19802154720 RST SM 0805 4K7 PM5 COL
3424 213810113101 RST CRB CFR-12 A 1R PM5
3425 19802151030 RST SM 0805 10K PM5 COL
3426 213810113101 RST CRB CFR-12 A 1R PM5
3427 213810113101 RST CRB CFR-12 A 1R PM5
3428 213810113225 RST CRB CFR-12 A 2M2 PM5
3429 232273061155 RST SM 0805 RC11 1M5 PM5
3430 19802151010 RST SM 0805 1R PM5 COL
3431 19802151820 RST SM 0805 1K8 PM5 COL
3432 231291515491 RST MFLM MBB0207A 549R PM1
3433 231291512672 RST MFLM MBB0207A 2K67 PM1
3434 19802154720 RST SM 0805 4K7 PM5 COL
3441 231291513903 RST MFLM MBB0207A 39K PM1
3442 232224182204 RST MGL VR25 A 220K PM1
3443 213810113683 RST CRB CFR-12 A 68K PM5
3444 19802190020 RST SM 0805 JUMP. 0R05 COL
3446 19802151230 RST SM 0805 12K PM5 COL
3450 230620403828 RST FUSE NFR25 S 8R2 PM5
3451 19802151220 RST SM 0805 1K2 PM5 COL
3456 230620403828 RST FUSE NFR25 S 8R2 PM5
3457 19802151220 RST SM 0805 1K2 PM5 COL
3458 213810113103 RST CRB CFR-12 A 10K PM5
3462 213810113103 RST CRB CFR-12 A 10K PM5
3464 19802151530 RST SM 0805 15K PM5 COL
3465 213810113103 RST CRB CFR-12 A 10K PM5
3466 213810113103 RST CRB CFR-12 A 10K PM5
3467 19802154720 RST SM 0805 4K7 PM5 COL
3468 213810113472 RST CRB CFR-12 A 4K7 PM5
3469 213811273473 RST CRB CFR-25 A 47K PM5
3470 213810113221 RST CRB CFR-12 A 220R PM5
3471 213810113473 RST CRB CFR-12 A 47K PM5
3472 231291511503 RST MFLM MBB0207A 15K PM1
3473 231291511003 RST MFLM MBB0207A 10K PM1
3474 231291511504 RST MFLM MBB0207A 150K PM1
3475 213811273103 RST CRB CFR-25 A 10K PM5
3476 232224181005 RST MGL VR25 A 1M PM1
3491 19802154730 RST SM 0805 47K PM5 COL
3492 19802154730 RST SM 0805 47K PM5 COL
3494 19802151010 RST SM 0805 1R PM5 COL
3495 213810113101 RST CRB CFR-12 A 1R PM5
3501 213810500335 RST MOX5W RSM5WLS 680R PM5
3502 213810500442 RST MOX5W RSM5WLS 5K6 PM5
3503 213810113479 RST CRB CFR-12 A 47R PM5
3504 213810113103 RST CRB CFR-12 A 10K PM5
3505 213810500335 RST MOX5W RSM5WLS 680R PM5
3506 213810500404 RST MOX 7W RSH S 1R5 PM5
3507 231291516809 RST MFLM MBB0207A 68R PM1
3508 213811273221 RST CRB CFR-25 A 220R PM5
3515 213810500074 RST MOX5W RSM5WLS 150R PM5
3516 213810500076 RST MOX5W RSM5WLS 330R PM5
3517 213810113471 RST CRB CFR-12 A 470R PM5
3518 213810113471 RST CRB CFR-12 A 470R PM5
3519 231291516809 RST MFLM MBB0207A 68R PM1
3521 231291516809 RST MFLM MBB0207A 68R PM1
3522 231291514708 RST MFLM MBB0207A 4R7 PM1
3523 230620403159 RST FUSE NFR25 S 15R PM5
3524 230620403159 RST FUSE NFR25 S 15R PM5
3525 213811273471 RST CRB CFR-25 A 470R PM5
3527 19802151030 RST SM 0805 10K PM5 COL
3528 213810113101 RST CRB CFR-12 A 1R PM5
3529 213810113103 RST CRB CFR-12 A 10K PM5
3530 19802151820 RST SM 0805 1K8 PM5 COL
3531 213811273122 RST CRB CFR-25 A 1K2 PM5
3541 213810113109 RST CRB CFR-12 A 10R PM5
3542 231291512001 RST MFLM MBB0207A 2R PM1
3544 231291511009 RST MFLM MBB0207A 10R PM1
3545 213810500095 RST MOX 7W RSH S 33R PM5
3546 213810113479 RST CRB CFR-12 A 47R PM5
3551 230620403108 RST FUSE NFR25 S 1R PM5
3552 230620403108 RST FUSE NFR25 S 1R PM5
3553 231291513302 RST MFLM MBB0207A 3K3 PM1
3554 231291511203 RST MFLM MBB0207A 12K PM1

3555 19802151030 RST SM 0805 10K PM5 COL
3556 232273061202 RST SM 0805 RC11 2K PM5
3566 213810113472 RST CRB CFR-12 A 4K7 PM5
3569 232220733108 RST FUSE NFR25H A 1R PM5
3570 231291512202 RST MFLM MBB0207A 2K2 PM1
3571 213811273471 RST CRB CFR-25 A 470R PM5
3572 213811273471 RST CRB CFR-25 A 470R PM5
3576 231291512202 RST MFLM MBB0207A 2K2 PM1
3577 232220733108 RST FUSE NFR25H A 1R PM5
3578 231291514709 RST MFLM MBB0207A 47R PM1
3579 231291511808 RST MFLM MBB0207A 1R8 PM1
3580 231291512208 RST MFLM MBB0207A 2R2 PM1
3581 231291511801 RST MFLM MBB0207A 180R PM1
3582 231291511808 RST MFLM MBB0207A 1R8 PM1
3585 213810113333 RST CRB CFR-12 A 33K PM5
3586 213810113433 RST CRB CFR-12 A 43K PM5
3587 213810113823 RST CRB CFR-12 A 82K PM5
3589 213810113333 RST CRB CFR-12 A 33K PM5
3590 232220533479 RST FUSE NFR25 A 47R PM5
3591 232220533479 RST FUSE NFR25 A 47R PM5
3592 231291514701 RST MFLM MBB0207A 470R PM1
3593 231291514709 RST MFLM MBB0207A 47R PM1
3594 213866000029 NTC DC TTC-301 S 3R PM5
3601 232224213224 RST MGL VR37 A 220K PM5
3605 232224213104 RST MGL VR37 A 1K PM5
3606 232224213105 RST MGL VR37 A 1M PM5
3607 232224213105 RST MGL VR37 A 1M PM5
3608 231291511202 RST MFLM MBB0207A 1K2 PM1
3609 212010128152 RST CMP ERC12 A 1K5 PM10
3612 213810113823 RST CRB CFR-12 A 82K PM5
3615 231291511802 RST MFLM MBB0207A 1K8 PM1
3616 232224213475 RST MGL VR37 A 4M7 PM5
3617 212010128222 RST CMP ERC12 A 2K2 PM10
3618 198021515450 RST SM 0805 150K PM5 COL
3622 19802151040 RST SM 0805 1K PM5 COL
3623 213810113103 RST CRB CFR-12 A 10K PM5
3624 19802151040 RST SM 0805 1K PM5 COL
3625 213810113103 RST CRB CFR-12 A 10K PM5
3626 19802151040 RST SM 0805 1K PM5 COL
3627 213810113103 RST CRB CFR-12 A 10K PM5
3628 19802151040 RST SM 0805 1K PM5 COL
3629 213810113103 RST CRB CFR-12 A 10K PM5
3630 19802151040 RST SM 0805 1K PM5 COL
3631 213810113333 RST CRB CFR-12 A 33K PM5
3632 19802151040 RST SM 0805 1K PM5 COL
3633 213810113333 RST CRB CFR-12 A 33K PM5
3634 213811273222 RST CRB CFR-25 A 2K2 PM5
3653 213811273129 RST CRB CFR-25 A 12R PM5
3656 19802154720 RST SM 0805 4K7 PM5 COL
3658 213810113332 RST CRB CFR-12 A 3K3 PM5
3659 231291515602 RST MFLM MBB0207A 5K6 PM1
3660 19802155620 RST SM 0805 5K6 PM5 COL
3661 19802154790 RST SM 0805 47R PM5 COL
3662 19802154720 RST SM 0805 4K7 PM5 COL
3663 232273464702 RST SM 0805 RC12H 4K7 PM1
3664 19802153320 RST SM 0805 3K3 PM5 COL
3665 19802151030 RST SM 0805 10K PM5 COL
3666 19802151050 RST SM 0805 1M PM5 COL
3667 19802154720 RST SM 0805 4K7 PM5 COL
3668 19802152230 RST SM 0805 22K PM5 COL
3671 232224181005 RST MGL VR25 A 1M PM1
3672 232220533478 RST FUSE NFR25 A 4R7 PM5
3673 19802151050 RST SM 0805 1M PM5 COL
3674 231291511002 RST MFLM MBB0207A 1K PM1
3675 231291511009 RST MFLM MBB0207A 10R PM1
3676 231291511003 RST MFLM MBB0207A 10K PM1
3677 212010592444 RST MOX 2W RSH S 68R PM5
3678 213811273101 RST CRB CFR-25 A 1R PM5
3679 213811273471 RST CRB CFR-25 A 470R PM5
3680 213811273103 RST CRB CFR-25 A 10K PM5
3681 231291511009 RST MFLM MBB0207A 10R PM1
3682 232224213104 RST MGL VR37 A 1K PM5
3683 212010128102 RST CMP ERC12 A 1K PM10
3684 231291514702 RST MFLM MBB0207A 4K7 PM1
3685 213811273103 RST CRB CFR-25 A 10K PM5
3686 19802152720 RST SM 0805 2K7 PM5 COL
3687 19802151030 RST SM 0805 10K PM5 COL
3688 19802153930 RST SM 0805 39K PM5 COL
3689 213810113153 RST CRB CFR-12 A 15K PM5
3690 213810113102 RST CRB CFR-12 A 1K PM5
3691 212010128152 RST CMP ERC12 A 1K5 PM10
3692 232224213684 RST MGL VR37 A 680K PM5
3693 231291511004 RST MFLM MBB0207A 1K PM1
3694 231291518203 RST MFLM MBB0207A 82K PM1
3695 213836500102 RTRM CER LIN 20K H VG067TL1
3696 231291511005 RST MFLM MBB0207A 1M PM1
3697 231291517503 RST MFLM MBB0207A 75K PM1
3698 213836500102 RTRM CER LIN 20K H VG067TL1
3699 19802151020 RST SM 0805 1K PM5 COL



5101 313816873611 LINE FILTER (HJC-K8259)
5130 313818873541 TFM SMT LAYER SRW42ES-T70V11
5131 313818873551 TFM SMT LAYER SRW19LES-T14V1
5132 242253600036 IND FXD TSL0808S 1U PM10
5301 242253597416 IND FXD SP0406A 33U PM10
5501 313817871331 DRIVER TRANSF.
5502 313816874061 BEAD BF30UTA-3.5X5X1B
5503 313816873551 LINEARITY COIL(54A-9050H)
5504 313816873541 LINEARITY COIL(54A-9049H)
5505 313816874061 BEAD BF30UTA-3.5X5X1B
5540 313816874061 BEAD BF30UTA-3.5X5X1B
5541 313811878961 G DRIVER TRANSFORMER
5542 242253600036 IND FXD TSL0808S 1U PM10
5543 313812874431 HOR.CENTERING TRAN.
5544 313811878951 H SHIFT CHOKE COIL
5545 313812874421 PUNK HEAD CHOKE
5601 313812874411 DAF TRANSFORMER
5670 242253597069 IND FXD SP0305A 4U7 PM10
5671 313818873701 TFM LOT LAYER 12MM WIRE
5672 242253600036 IND FXD TSL0808S 1U PM10



6101 932218229682 BRIDGE GBU6J-B5 (PAJ) B
6104 933703700133 DIO REC BYV26E A (PHSE)
6109 319801021290 DIO REG BZX79-C12 A COL
6114 933952580685 DIO SIG SM BA/103 (TEGO)
6115 933952580685 DIO SIG SM BA/103 (TEGO)
6116 933952580685 DIO SIG SM BA/103 (TEGO)
6117 933913910115 DIO SIG SM BAS32L (PHSE)
6124 933497950683 DIO REC RGP10J A (GI)
6125 933913910115 DIO SIG SM BAS32L (PHSE)
6131 932212636682 DIO REC 31DF6-FC5 (NIEC)
6133 932212636682 DIO REC 31DF6-FC5 (NIEC)
6134 932208187683 DIO REC BYW98-2 (ST)
6135 932208187683 DIO REC BYW98-2 (ST)
6137 932208187683 DIO REC BYW98-2 (ST)
6139 933957760683 DIO REC SB140 A (GI)
6140 933957760683 DIO REC SB140 A (GI)
6143 933751660683 DIO REC RGP10D A (GI)
6145 319801010010 DIO SIG 1N4148 (COL)
6147 933957760683 DIO REC SB140 A (GI)
6148 933117760133 DIO REG BZX79-C7V5 A (PHSE)
6149 319801010010 DIO SIG 1N4148 (COL)
6150 319801025180 DIO REG BZX79-C5V1 A COL
6152 933913910115 DIO SIG SM BAS32L (PHSE)
6153 933913910115 DIO SIG SM BAS32L (PHSE)
6160 933913910115 DIO SIG SM BAS32L (PHSE)
6172 933117960133 DIODE BZX79-C51
6174 319801025680 DIO REG BZX79-C5V6 A COL
6176 933913910115 DIO SIG SM BAS32L (PHSE)
6177 933952580685 DIO SIG SM BA/103 (TEGO)
6303 319801010620 DIO SIG SM BA/99 (COL)
6304 319801010620 DIO SIG SM BA/99 (COL)
6391 319801010620 DIO SIG SM BA/99 (COL)
6392 319801010620 DIO SIG SM BA/99 (COL)
6422 933957760683 DIO REC SB140 A (GI)
6423 933913910115 DIO SIG SM BAS32L (PHSE)
6424 319801010010 DIO SIG 1N4148 (COL)
6426 319801010010 DIO SIG 1N4148 (COL)
6462 933117900133 DIO REG BZX79-C30 A (PHSE)
6463 933913910115 DIO SIG SM BAS32L (PHSE)
6464 319801026880 DIO REG BZX79-C6V8 A COL
6501 933493960683 DIO REC RGP10G A (GI)
6502 933751660683 DIO REC RGP10D A (GI)
6503 319801010010 DIO SIG 1N4148 (COL)
6506 933543490133 DIO REC BYV27-50 A (PHSE)
6507 319801021890 DIO REG BZX79-C18 A COL
6515 933703700133 DIO REC BYV26E A (PHSE)
6518 932213602687 DIO REC 5TU252C (TSOJ)
6540 933497950683 DIO REC RGP10J A (GI)
6542 319801010010 DIO SIG 1N4148 (COL)
6543 932211574682 DIO REC 31DF4-FC5 (NIEC)
6544 933751660683 DIO REC RGP10D A (GI)
6545 933751660683 DIO REC RGP10D A (GI)
6566 319801010010 DIO SIG 1N4148 (COL)
6567 933504400683 DIO REC RGP15G A (GI)
6621 319801010010 DIO SIG 1N4148 (COL)
6622 319801025180 DIO REG BZX79-C5V1 A COL
6651 933751660683 DIO REC RGP10D A (GI)
6652 319801025180 DIO REG BZX79-C5V1 A COL
6653 933913910115 DIO SIG SM BAS32L (PHSE)
6654 933913910115 DIO SIG SM BAS32L (PHSE)
6655 319801025180 DIO REG BZX79-C5V1 A COL
6656 933913910115 DIO SIG SM BAS32L (PHSE)
6671 933497950683 DIO REC RGP10J A (GI)
6672 932210388682 DIO REC 31DF6 A (INR0)
6673 933751660683 DIO REC RGP10D A (GI)
6674 933612320113 DIO REC BY584 A (PHSE)

Spare Parts List



7121	932214039682	IC STR-F6456(LF1352) (SAKJ)
7122	933967380685	TRA SIG SMBC858C (ONSE)
7130	932214014667	OPT CP TCET1103(G) (VISH)
7132	933567120126	TRA SIG BC516 (PHSE)
7133	932206519687	TRA POW BUX87 (ST)
7134	933953420676	TRA SIG TBC338-40 (TOSJ)
7135	932214014667	OPT CP TCET1103(G) (VISH)
7143	932209200687	IC L4940V5 (ST)
7144	933553530676	TRA SIG TBC548C (TOSJ)
7145	932209265685	TRA SIG SMMUN2211J (ONSE)
7155	932208367676	IC TL431CZ S(ST)
7161	933953420676	TRA SIG TBC338-40 (TOSJ)
7301	823827443451	CPU IC (6148-K420PH-50A)
7301	823827443451	CPU IC (6148-K420PH-50A)
7302	933967380685	TRA SIG SMBC858C (ONSE)
7303	933967310685	TRA SIG SMBC848C (ONSE)
7304	932209265685	TRA SIG SMMUN2211J (ONSE)
7336	932212662682	IC M24C16-BN6 (ST)
7363	93400610682	IC MC7812CT (MOTA)
7364	933920810682	IC L7808CV (ST)
7391	932209265685	TRA SIG SMMUN2211J (ONSE)
7392	933967380685	TRA SIG SMBC858C (ONSE)
7404	933282660652	IC HEF4053BP (PHSE)
7421	935267452112	IC TDA4856/V3 (PHSE)
7422	933953420676	TRA SIG TBC338-40 (TOSJ)
7423	933953410676	TRA SIG TBC328-40 (TOSJ)
7424	932209265685	TRA SIG SMMUN2211J (ONSE)
7425	933553530676	TRA SIG TBC548C (TOSJ)
7426	933773860676	TRA SIG TBC558C (TOSJ)
7427	933967380685	TRA SIG SMBC858C (ONSE)
7461	933237780126	TRA SIG BC546B (PHSE)
7462	933553530676	TRA SIG TBC548C (TOSJ)
7463	933773860676	TRA SIG TBC558C (TOSJ)
7464	319802043020	TRA SIG BF423 (COL)
7465	319802043010	TRA SIG BF422 (COL)
7466	932209265685	TRA SIG SMMUN2211J (ONSE)
7501	934000540115	FET SIG SMBSP126 (PHSE)
7502	932214442671	TRA POW 2SC5445(AS) (TOSJ)
7503	932205702687	TRA POW BD533 (ST)
7504	932205703687	TRA POW BD534 (ST)
7505	933984890682	IC LM358N (ST)
7541	932218090687	TRANS IRF730B
7542	932204822682	TRA POW 2SC2344E (TSAJ)
7543	932204823682	TRA POW 2SA1011E (TSAJ)
7544	933967380685	TRA SIG SMBC858C (ONSE)
7545	319802043010	TRA SIG BF422 (COL)
7566	932209265685	TRA SIG SMMUN2211J (ONSE)
7567	931900234682	IC STV9379 (ST)
7586	933984890682	IC LM358N (ST)
7587	933221930126	TRA SIG BC637 (PHSE)
7588	933221960126	TRA SIG BC638 (PHSE)
7601	932206519687	TRA POW BUX87 (ST)
7621	932214232687	FET POW IRF640A (FSC0)
7622	932214562667	FET POW SLA5058 (SAKJ)
7628	932209265685	TRA SIG SMMUN2211J (ONSE)
7629	932209265685	TRA SIG SMMUN2211J (ONSE)
7630	932209265685	TRA SIG SMMUN2211J (ONSE)
7631	932209265685	TRA SIG SMMUN2211J (ONSE)
7632	932209265685	TRA SIG SMMUN2211J (ONSE)
7633	932209265685	TRA SIG SMMUN2211J (ONSE)
7651	932212152682	IC L4990A (ST)
7652	933553530676	TRA SIG TBC548C (TOSJ)
7653	933967380685	TRA SIG SMBC858C (ONSE)
7654	933967310685	TRA SIG SMBC848C (ONSE)
7671	934003960126	FET SIG BSN254A (PHSE)
7672	932214646687	FET POW IRF740A (FSC0)
7673	932213498687	FET POW FSF7UM-16A (MITJ)
7674	933553530676	TRA SIG TBC548C (TOSJ)

1161 VideoPCB



2702	223858015636	CER2 0805 X7R50V 10N PM10
2704	203803522801	ELCAP BP NK160V S 1U PM20
2705	203803513907	ELCAP RGA 250V S 1U PM20
2706	242254944346	SURGE PROT.DSP-201M-D04F
2707	223891015649	CER2 0805 X7R25V 1N PM10
2708	223891015649	CER2 0805 X7R25V 1N PM10
2709	223891015649	CER2 0805 X7R25V 1N PM10
2710	223886115479	CER1 0805 NP050V 47P PM5
2720	223886115479	CER1 0805 NP050V 47P PM5
2722	223858015636	CER2 0805 X7R50V 10N PM10
2724	203803522801	ELCAP BP NK160V S 1U PM20
2725	203803513907	ELCAP RGA 250V S 1U PM20
2726	242254944346	SURGE PROT.DSP-201M-D04F
2727	223891015649	CER2 0805 X7R25V 1N PM10
2736	223858019814	CER2 0805 Y5V50V 220N P8020
2740	223886115479	CER1 0805 NP050V 47P PM5
2742	223858015636	CER2 0805 X7R50V 10N PM10
2744	203803522801	ELCAP BP NK160V S 1U PM20
2745	203803513907	ELCAP RGA 250V S 1U PM20
2746	242254944346	SURGE PROT.DSP-201M-D04F
2748	203803513301	ELCAP RGA 25V S 47U PM20
2749	223891015649	CER2 0805 X7R25V 1N PM10
2750	223891015649	CER2 0805 X7R25V 1N PM10
2751	223891015649	CER2 0805 X7R25V 1N PM10
2752	203803513707	ELCAP RGA 1V S 47U PM20
2753	203803513907	ELCAP RGA 250V S 1U PM20
2756	223886115101	CER1 0805 NP050V 1P PM5
2757	223886115101	CER1 0805 NP050V 1P PM5
2760	223891015649	CER2 0805 X7R25V 1N PM10
2761	223555900099	CER2 DC 2KVS 10N PM20
2762	225260214416	CER2 DC X7R 2KVS 470P PM10
2763	225261818021	CER2 DC Y5P5V S 1N PM10
2764	202055890557	CERHDT RR 1KVS 1N PM10
2765	225260215216	CER2 DC X7R 2KVS 220P PM10
2766	223858016623	CER2 0805 X7R50V 47P PM10
2767	223891015649	CER2 0805 X7R25V 1N PM10
2768	223891015649	CER2 0805 X7R25V 1N PM10
2770	203803513501	ELCAP RGA 50V S 10U PM20
2771	223891015649	CER2 0805 X7R25V 1N PM10
2772	203803513301	ELCAP RGA 25V S 47U PM20
2773	223891015649	CER2 0805 X7R25V 1N PM10
2774	223891015649	CER2 0805 X7R25V 1N PM10
2775	203803513204	ELCAP RGA 16V S 330U PM20
2776	223891015649	CER2 0805 X7R25V 1N PM10
2777	203803513301	ELCAP RGA 25V S 47U PM20
2778	223891015649	CER2 0805 X7R25V 1N PM10
2779	203803513707	ELCAP RGA 1V S 47U PM20
2780	222236525104	CAP MPOL 1VS 1N PM10
2781	203803513907	ELCAP RGA 250V S 1U PM20
2782	222236555103	CAP MPOL 4VS 10N PM10
2783	223886115229	CER1 0805 NP050V 22P PM5
2784	223886115229	CER1 0805 NP050V 22P PM5
2785	223886115229	CER1 0805 NP050V 22P PM5
2786	223886115229	CER1 0805 NP050V 22P PM5
2787	223891015649	CER2 0805 X7R25V 1N PM10
2788	223891015649	CER2 0805 X7R25V 1N PM10
2789	223886115101	CER1 0805 NP050V 1P PM5
2790	223886115101	CER1 0805 NP050V 1P PM5
2791	203803513201	ELCAP RGA 16V S 1U PM20
2792	223858016623	CER2 0805 X7R50V 47P PM10
2793	223886115101	CER1 0805 NP050V 1P PM5
2797	222236555103	CAP MPOL 4VS 10N PM10
2798	203803513201	ELCAP RGA 16V S 1U PM20
2799	223891015649	CER2 0805 X7R25V 1N PM10
2801	223858015636	CER2 0805 X7R50V 10N PM10
2802	223886115101	CER1 0805 NP050V 1P PM5
2803	223891015649	CER2 0805 X7R25V 1N PM10
2804	223886115181	CER1 0805 NP050V 180P PM5
2805	223891015649	CER2 0805 X7R25V 1N PM10
2806	223891015649	CER2 0805 X7R25V 1N PM10
2807	223891015649	CER2 0805 X7R25V 1N PM10
2811	203803513907	ELCAP RGA 250V S 1U PM20
2812	223858016614	CER2 0805 X7R50V 1N PM10
2813	223858016621	CER2 0805 X7R50V 3N3 PM10
2814	223891015649	CER2 0805 X7R25V 1N PM10
2815	223891015649	CER2 0805 X7R25V 1N PM10
2821	223858016614	CER2 0805 X7R50V 1N PM10
2822	223858016621	CER2 0805 X7R50V 3N3 PM10
2831	223858016614	CER2 0805 X7R50V 1N PM10
2832	223858016621	CER2 0805 X7R50V 3N3 PM10



3701	232273467509	RST SM 0805RC12H 75R PM1
3702	319802154790	RST SM 0805 47R PM5 COL
3703	319802152290	RST SM 0805 22R PM5 COL
3704	232273061569	RST SM 0805RC11 56RPM5
3705	319802151050	RST SM 0805 1M PM5 COL
3706	231291515603	RST MFLM MBB0207A 56K PM1
3707	213810113224	RST CRB CFR-12 A 220K PM5
3708	319802158230	RST SM 0805 82K PM5 COL
3709	212010128479	RST CMP ERC12 A 47R PM10
3710	319802151020	RST SM 0805 1K PM5 COL

3711	319802151230	RST SM 0805 12K PM5 COL
3712	319802151020	RST SM 0805 1K PM5 COL
3713	319802151010	RST SM 0805 1R PM5 COL
3714	319802151010	RST SM 0805 1R PM5 COL
3715	319802151010	RST SM 0805 1R PM5 COL
3717	319802154710	RST SM 0805 470R PM5 COL
3718	319802154710	RST SM 0805 470R PM5 COL
3721	232273467509	RST SM 0805RC12H 75R PM1
3722	319802154790	RST SM 0805 47R PM5 COL
3723	319802152290	RST SM 0805 22R PM5 COL
3724	232273061569	RST SM 0805RC11 56RPM5
3725	319802151050	RST SM 0805 1M PM5 COL
3726	231291515603	RST MFLM MBB0207A 56K PM1
3727	213810113224	RST CRB CFR-12 A 220K PM5
3728	319802158230	RST SM 0805 82K PM5 COL
3729	212010128479	RST CMP ERC12 A 47R PM10
3730	319802151020	RST SM 0805 1K PM5 COL
3731	319802151230	RST SM 0805 12K PM5 COL
3732	319802152220	RST SM 0805 2K2 PM5 COL
3733	319802151810	RST SM 0805 180R PM5 COL
3734	319802151010	RST SM 0805 1R PM5 COL
3735	319802154710	RST SM 0805 470R PM5 COL
3736	319802151010	RST SM 0805 1R PM5 COL
3737	319802151050	RST SM 0805 1M PM5 COL
3738	319802151050	RST SM 0805 1M PM5 COL
3741	232273467509	RST SM 0805RC12H 75R PM1
3742	319802154790	RST SM 0805 47R PM5 COL
3743	319802152290	RST SM 0805 22R PM5 COL
3744	232273061569	RST SM 0805RC11 56RPM5
3745	319802151050	RST SM 0805 1M PM5 COL
3746	231291515603	RST MFLM MBB0207A 56K PM1
3747	213810113224	RST CRB CFR-12 A 220K PM5
3748	319802158230	RST SM 0805 82K PM5 COL
3749	212010128479	RST CMP ERC12 A 47R PM10
3750	319802151020	RST SM 0805 1K PM5 COL
3751	319802151230	RST SM 0805 12K PM5 COL
3755	319802190020	RST SM 0805JUMP. 0R05 COL
3760	212010128153	RST CMP ERC12 A 15K PM10
3761	231291511503	RST MFLM MBB0207A 15K PM1
3763	212010128152	RST CMP ERC12 A 1K5 PM10
3765	231291511804	RST MFLM MBB0207A 180K PM1
3766	319802151010	RST SM 0805 1R PM5 COL
3767	319802151010	RST SM 0805 1R PM5 COL
3768	319802151020	RST SM 0805 1K PM5 COL
3769	319802151520	RST SM 0805 1K5 PM5 COL
3783	319802151020	RST SM 0805 1K PM5 COL
3785	319802151020	RST SM 0805 1K PM5 COL
3786	319802151030	RST SM 0805 10K PM5 COL
3787	319802153320	RST SM 0805 3K3 PM5 COL
3788	319802151010	RST SM 0805 1R PM5 COL
3789	319802151010	RST SM 0805 1R PM5 COL
3790	319802151030	RST SM 0805 10K PM5 COL
3791	319802153320	RST SM 0805 3K3 PM5 COL
3792	232273464702	RST SM 0805RC12H 4K7 PM1
3801	319802154720	RST SM 0805 4K7 PM5 COL
3802	319802155620	RST SM 0805 5K6 PM5 COL
3803	319802154720	RST SM 0805 4K7 PM5 COL
3804	319802151050	RST SM 0805 1M PM5 COL
3805	319802151030	RST SM 0805 10K PM5 COL
3806	319802153310	RST SM 0805 330R PM5 COL
3807	319802151530	RST SM 0805 15K PM5 COL
3808	319802151230	RST SM 0805 12K PM5 COL
3809	319802152240	RST SM 0805 220K PM5 COL
3811	232273061184	RST SM 0805RC11 180KPM5
3812	319802156840	RST SM 0805 680K PM5 COL
3813	319802154730	RST SM 0805 47K PM5 COL
3815	319802151030	RST SM 0805 10K PM5 COL
3816	319802151020	RST SM 0805 1K PM5 COL
3821	232273061184	RST SM 0805RC11 180KPM5
3822	319802156840	RST SM 0805 680K PM5 COL
3823	319802154730	RST SM 0805 47K PM5 COL
3825	319802151030	RST SM 0805 10K PM5 COL
3831	232273061184	RST SM 0805RC11 180KPM5
3832	319802156840	RST SM 0805 680K PM5 COL
3833	319802154730	RST SM 0805 47K PM5 COL
3835	319802151030	RST SM 0805 10K PM5 COL
3836	319802151030	RST SM 0805 10K PM5 COL
3841	319802151030	RST SM 0

Spare Parts List (Continued)

210B4 M25P

41

Go to cover page

5701 242253597069 IND FXD SP0305A 4U7 PM10
5702 313817876911 COIL 0.12UH PM10
5703 242254944197 IND FXD 0805 EMI1MHZ 220R
5704 313816879121 FERRITE BEAD SMD (FB423226T-
5721 313817876911 COIL 0.12UH PM10
5722 242254944197 IND FXD 0805 EMI1MHZ 220R
5731 313817876911 COIL 0.12UH PM10
5732 242254944197 IND FXD 0805 EMI1MHZ 220R
5733 242254944197 IND FXD 0805 EMI1MHZ 220R
5734 242253597069 IND FXD SP0305A 4U7 PM10
5735 242254944197 IND FXD 0805 EMI1MHZ 220R
5736 242254944197 IND FXD 0805 EMI1MHZ 220R
5737 242254944197 IND FXD 0805 EMI1MHZ 220R
5760 313816874511 FERRITE BEAD
5761 242254944197 IND FXD 0805 EMI1MHZ 220R
5762 242254944197 IND FXD 0805 EMI1MHZ 220R
5763 242254944197 IND FXD 0805 EMI1MHZ 220R
5764 242254944197 IND FXD 0805 EMI1MHZ 220R
5765 242254944197 IND FXD 0805 EMI1MHZ 220R
5766 242253597069 IND FXD SP0305A 4U7 PM10
5767 313816874511 FERRITE BEAD
5768 242254942026 IND FXD BEAD EMI1MHZ 50R
5781 242253597069 IND FXD SP0305A 4U7 PM10
5782 242253597069 IND FXD SP0305A 4U7 PM10
5783 313817878601 BEAD 07UH VERT.
5791 242253597069 IND FXD SP0305A 4U7 PM10
5801 242254944197 IND FXD 0805 EMI1MHZ 220R



6701 933952580685 DIO SIG SM BAV103 (TEGO)
6702 933952580685 DIO SIG SM BAV103 (TEGO)
6703 933952580685 DIO SIG SM BAV103 (TEGO)
6704 933952580685 DIO SIG SM BAV103 (TEGO)
6705 933913910115 DIO SIG SM BAS32L (PHSE)
6721 933952580685 DIO SIG SM BAV103 (TEGO)
6722 933952580685 DIO SIG SM BAV103 (TEGO)
6723 933952580685 DIO SIG SM BAV103 (TEGO)
6724 933952580685 DIO SIG SM BAV103 (TEGO)
6725 933913910115 DIO SIG SM BAS32L (PHSE)
6731 933913910115 DIO SIG SM BAS32L (PHSE)
6732 319801010620 DIO SIG SM BAW99 (COL)
6741 933952580685 DIO SIG SM BAV103 (TEGO)
6742 933952580685 DIO SIG SM BAV103 (TEGO)
6743 933952580685 DIO SIG SM BAV103 (TEGO)
6744 933952580685 DIO SIG SM BAV103 (TEGO)
6745 933913910115 DIO SIG SM BAS32L (PHSE)
6761 933493960683 DIO REC RGP10G A (GI)
6762 933117900133 DIO REG BZX79-C30 A (PHSE)
6801 933913910115 DIO SIG SM BAS32L (PHSE)
6802 933913910115 DIO SIG SM BAS32L (PHSE)
6803 933913910115 DIO SIG SM BAS32L (PHSE)
6811 933137380215 DIO REG SM BZX84-C4V7 (PHSE)
6812 933913910115 DIO SIG SM BAS32L (PHSE)
6813 319801010620 DIO SIG SM BAV99 (COL)
6821 933137380215 DIO REG SM BZX84-C4V7 (PHSE)
6822 933913910115 DIO SIG SM BAS32L (PHSE)
6823 319801010620 DIO SIG SM BAV99 (COL)
6831 933137380215 DIO REG SM BZX84-C4V7 (PHSE)
6832 933913910115 DIO SIG SM BAS32L (PHSE)
6833 319801010620 DIO SIG SM BAV99 (COL)



7701 935264061112 IC TDA4887PS/V1 (PHSE)
7705 932213801667 IC LM2402T (NSCO)
7706 319802043010 TRA SIG BF422 (COL)
7707 319802043010 TRA SIG BF422 (COL)
7726 319802043010 TRA SIG BF422 (COL)
7727 319802043010 TRA SIG BF422 (COL)
7746 319802043010 TRA SIG BF422 (COL)
7747 319802043010 TRA SIG BF422 (COL)
7781 932218254682 IC WT6803-N160PH-06AB(WESE)
7782 932209265685 TRA SIG SMMUN2211J (ONSE)
7783 932209265685 TRA SIG SMMUN2211J (ONSE)
7801 932216309682 IC WT62P2 (WESE)
7801 932216309682 IC WT62P2 (WESE)
7801 932206163682 IC TL072CN (ST)
7802 933669110652 IC 74HC4066N (PHSE)
7803 319802043020 TRA SIG BF423 (COL)
7804 319802043020 TRA SIG BF423 (COL)
7805 319802043020 TRA SIG BF423 (COL)
7806 933706060112 IC PCF8574P (PHSE)
7807 933967310685 TRA SIG SMB848C (ONSE)
7808 319802043020 TRA SIG BF423 (COL)
7809 319802043020 TRA SIG BF423 (COL)
7810 319802043020 TRA SIG BF423 (COL)

1162 Terminal PCB



2001 202202000697 ELCAP SEA 10V S 220U PM20
2002 202202000699 ELCAP SEA 16V S 220U PM20
2003 203803500037 ELCAP SM 16VS 47U PM20
2004 203803500037 ELCAP SM 16VS 47U PM20
2005 203803500037 ELCAP SM 16VS 47U PM20
2007 203803500037 ELCAP SM 16VS 47U PM20
2008 223891015649 CER2 0805 X7R25V 1N PM10
2010 223891015649 CER2 0805 X7R25V 1N PM10
2011 203803500037 ELCAP SM 16VS 47U PM20
2013 203803500037 ELCAP SM 16VS 47U PM20
2017 223891015649 CER2 0805 X7R25V 1N PM10
2018 223886115109 CER1 0805 NP050V 10P PM5
2019 223886115109 CER1 0805 NP050V 10P PM5
2020 223886115109 CER1 0805 NP050V 10P PM5
2021 223886115109 CER1 0805 NP050V 10P PM5
2023 202202000697 ELCAP SEA 10V S 220U PM20
2025 202202000697 ELCAP SEA 10V S 220U PM20
2027 202202000697 ELCAP SEA 10V S 220U PM20
2031 223886115229 CER1 0805 NP050V 22P PM5
2032 223886115229 CER1 0805 NP050V 22P PM5
2033 223886115229 CER1 0805 NP050V 22P PM5
2034 223886115229 CER1 0805 NP050V 22P PM5
2035 223891015649 CER2 0805 X7R25V 1N PM10
2036 223891015649 CER2 0805 X7R25V 1N PM10



3001 319802152220 RST SM 0805 2K2 PM5 COL
3004 319802152220 RST SM 0805 2K2 PM5 COL
3006 319802154790 RST SM 0805 47R PM5 COL
3007 232273467509 RST SM 0805RC12H 75R PM1
3008 319802154790 RST SM 0805 47R PM5 COL
3009 232273467509 RST SM 0805RC12H 75R PM1
3010 319802154790 RST SM 0805 47R PM5 COL
3011 232273467509 RST SM 0805RC12H 75R PM1
3012 319802154710 RST SM 0805 470R PM5 COL
3013 319802154710 RST SM 0805 470R PM5 COL
3014 319802154710 RST SM 0805 470R PM5 COL
3015 319802154710 RST SM 0805 470R PM5 COL
3016 319802154790 RST SM 0805 47R PM5 COL
3017 232273467509 RST SM 0805RC12H 75R PM1
3018 319802152220 RST SM 0805 2K2 PM5 COL
3019 319802154790 RST SM 0805 47R PM5 COL
3020 232273467509 RST SM 0805RC12H 75R PM1
3021 319802154790 RST SM 0805 47R PM5 COL
3022 232273467509 RST SM 0805RC12H 75R PM1
3023 319802152220 RST SM 0805 2K2 PM5 COL



5001 242253597069 IND FXD SP0305A 4U7 PM10
5002 242253597069 IND FXD SP0305A 4U7 PM10
5003 242253597069 IND FXD SP0305A 4U7 PM10



7001 932214260682 IC AN5870 (MATJ)

1163 Control PCB



2891 223891015649 CER2 0805 X7R25V IN PM10
2892 223891015649 CER2 0805 X7R25V IN PM10
2893 223891015649 CER2 0805 X7R25V IN PM10



3891 231291511004 RST MFLM MBB0207A 1K PM1
3892 231291515603 RST MFLM MBB0207A 56K PM1
3893 231291514702 RST MFLM MBB0207A 4K7 PM1
3894 231291511503 RST MFLM MBB0207A 15K PM1
3895 231291512403 RST MFLM MBB0207A 24K PM1



5981 242254944197 IND FX 0805 EMI1MHZ 220R



6891 932214603682 LED VS L-3WYGW (KIEL)

1165 313817861951 MHR PCB



2192 203803456229 ELCAP VX 50VS 22U PM20
2193 203803521603 ELCAP GS 63VS 22U PM20
2194 203803511219 ELCAP REA 16V S 220U PM20
2195 222236555223 CAP MPOL 4VS 22N PM10



3191 231291519102 RST MFLM MBB0207A 9K1 PM1
3192 231291511503 RST MFLM MBB0207A 15K PM1
3193 212010590779 RST MOX 1W RSS A 270RPM5






5191 313816872691 MAINS HARMONIC COIL
5192 243853598058 IND FXD BEAD EMI1MHZ 80R




6191 319801010010 DIO SIG 1N4148 (COL)
6192 319801010070 DIO SIG BAV21 (COL)
6193 319801010070 DIO SIG BAV21 (COL)
6194 319801010010 DIO SIG 1N4148 (COL)

Repair Flow Chart

A. Power Supply Failure






Repair Flow Chart

Go to cover page

C. Horizontal deflection

output repair flow :



D. Vertical Deflection Failure

basic check
+15/-15V

Sympton :
one horizontal line
V_size is abnormal
too large/small (small)

check
3578,3580
good

No

replace
3578,3580,7567

check
+15V,3569,6567
good?

No

replace
3569,6567,7567

Ok


check 7567
pin2,pin3 ramp
exist ?

No

check
7421

check
3571,3572







Ok






Repair Flow Chart


Go to cover page

E. CPU
check list












Hor. Freq.(KHz)	Q6	Q5	Q4	Q3	Q2	Q1
~33.00	1	1	1	1	1	1
33.00~36.00	0	1	1	1	0	1
36.00~42.00	0	1	1	0	0	1
42.00~45.00	0	0	1	1	1	0
45.00~47.50	1	1	1	0	1	0
47.50~49.00	0	1	1	0	1	0
49.00~52.00	0	1	1	0	1	0
52.00~55.00	1	0	0	0	1	0
55.00~58.50	1	1	1	1	0	0
58.50~61.50	1	1	0	1	0	0
61.50~65.00	0	1	0	1	0	0
65.00~70.00	0	0	0	1	0	0
70.00~73.00	1	1	1	0	0	0
73.00~76.00	0	1	1	0	0	0
76.00~82.50	1	0	1	0	0	0
82.50~88.50	0	0	1	0	0	0
88.50~98.00	1	1	0	0	0	0
98.00~102.00	0	1	0	0	0	0
102.00~110.00	1	0	0	0	0	0
110.00~	0	0	0	0	0	0





Repair Flow Chart





Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

M25P 201B4 GENERAL PRODUCT SPECIFICATION

. MICRO PROCESSOR-BASED DIGITAL CONTROL WITH **34** FACTORY PRESETS AND **16** USER MODES TO ENSURE PICTURE CONFIGURATIONS ARE ALWAYS MAINTAINED WHEN SWITCH BETWEEN COMMON VIDEO MODES AND USER DEFINED CUSTOM MODES.

. USER FRIENDLY OSD DISPLAY FOR MODE IDENTIFICATION/ADJUSTMENT

. DDC 2B COMMUNICATION CAPABILITY

. MAX. RESOLUTION 1920 X 1440 NON-INTERLACED AT 75 HZ

. 21" 0.25MM AG MASK NF PICTURE TUBE

. EASY TILT & SWIVEL BASE

. FULL RANGE POWER SUPPLY 90 - 264 VAC

. CE ENVIRONMENTAL POLICY with MHR (Option)

. FLAT SQUARE TUBE TO REDUCE LIGHT REFLECTION

. POWER MANAGEMENT CAPABILITY

. LOW EMISSION TCO 99

. MOIRE' CANCELLATION

. AUTO CALIBRATION FUNCTION

. **sRGB**

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.	31	590	— 1	10	A4
TY		CHECK	DATE 2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

CONTENTS

- 1.0 Foreword
- 2.0 Product profile
- 2.1 CRT
- 2.2 Scanning frequencies
- 2.3 Video dot rate
- 2.4 Power input
- 2.5 Power consumption
- 2.6 Dimensions
- 2.7 Weight
- 2.8 Functions
- 2.9 Ambient temperature
- 2.10 Regulatory compliance (SAFETY, EMI/EMS)
- 3.0 Electrical characteristics
- 3.1 Interface signals
- 3.2 Interface
- 3.2.1 Cable
- 3.2.2 Adaptor
- 3.2.3 OSD function control
- 3.3 Timing requirement
- 3.3.1 Mode storing capacity
- 3.3.2 Factory preset timings
- 3.3.3 Horizontal scanning
- 3.3.4 Vertical scanning
- 3.4 Power input connection
- 3.5 Video amplifiers
- 3.6 Degaussing
- 3.7 Requirement for low emission
- 3.8 Power management
- 3.9 Display identification
- 4.0 Visual characteristics
- 4.1 Test conditions
- 4.2 Resolution
- 4.3 Brightness
- 4.4 Flagwaving - jitter
- 4.5 Image size
- 4.5.1 Actual display size
- 4.5.2 Max. scan size

CLASS NO.

21" AUTO SCAN CMTR

TYPE : 201B40/00C-M25P-201B4

BRAND : PHILIPS

8639 000 11832

2002-01-23

NAME ALEX CHEN

SUPERS.

31

590 — 2

10

A4

TY

CHECK

DATE 2002-01-23

Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

- 4.6 Image centering deviation
- 4.7 Picture shift range
- 4.8 Display dimension stability
- 4.9 Geometric distortions
- 4.10 Picture tilt
- 4.11 Image non-linearity
- 4.12 Mis-convergence
- 4.13 Focus check
- 4.14 Brightness uniformity
- 4.15 White color adjustment
- 4.16 White uniformity
- 4.17 Color tracking on full white pattern
- 4.18 Purity
- 4.19 Moir
 - 4.20 Ringing
 - 4.21 Tapping test
- 4.22 Distance between two monitors
- 5.0 Mechanical characteristics
 - 5.1 Controls
 - 5.2 Unit dimension / weight
 - 5.3 Tilt and swivel base
 - 5.4 Transportation packages
 - 5.4.1 Shipping dimension / weight
 - 5.4.2 Block unit / polarization
- 6.0 Environmental characteristics
 - 6.1 Susceptibility of display to external environment
 - 6.2 Transportation tests
 - 6.3 Display disturbances from external environment
 - 6.4 Display disturbances to external environment
 - 6.4.1 Ionization radiation
- 7.0 Reliability
 - 7.1 Mean time between failures
- 8.0 Quality assurance requirements
 - 8.1 Acceptance test
- 9.0 Serviceability

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.	31	590	— 3	10	A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

1.0 FOREWORD

This specification describes a 21" high resolution digitally controlled auto-scan color monitor with max. resolution up to 1920x1440/75Hz non-interlaced.

2.0 PRODUCT PROFILE

This display monitor unit is a complete color display monitor enclosed in PHILIPS global styling cabinet which has an integrated tilt and swivel base.

2.1 CRT

Type NR. : M51QBN291X115 (SAMSUNG)
 Dimensions : 21 FS
 Phosphor Pitch : 0.25 mm
 Phosphor : P22
 Mask : INVAR MASK
 Deflection angle : 90 deg
 Light transmission : 43%
 Surface of plate : AGARS
 EHT : 27.0 KV
 Useful screen (mm) : 406.4 X 304.8

2.2 Scanning frequencies

Hor. : 30 - 115KHz Ver. : 50 - 160 Hz

2.3 Video dot rate : 297MHz

2.4 Power input : 90 - 264 Vac, 47-63 Hz

2.5 Power consumption : **115W Typ. / 130 W Max.**

2.6 Dimensions : 482(W) x 476(H) x 467(D) mm

2.7 Weight : 24.0 ± 0.5 kg

2.8 Functions :

- (1) R/G/B separate analog inputs, H/V composite sync,
- (2) Automatic (Power on) and manual degaussing circuit.

2.9 Ambient temperature : 0 - 35 C

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 4	10
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

2.10 Regulatory compliance:

- (1) Safety : UL 1950
: CSAC22.2 NO. 950
: IEC950/ EN60950
- (2) EMI : FCC PART 15 class B
: D.O.C. Class B
: EN55022 Class B
: CE mark
: CNS 13438
EMS : EN61000-4-3(80% 1KHz AM modulation) picture jitter <2mm
- (3) X-RAY Radiation requirement / regulation
: DHHS 21 CFR Subchapter J.
: ROEV /08.01.1987
- (4) Low Radiation
: TCO99
- (5) Environmental
: Per CE and BU policy
- (6) Ergonomic Requirements
: ZH 1/618
: EN 9241-3/ ISO 9241-3(7/92) / ISO 9241-8
- (7) Harmonic distortion: Meet IEC 1000-3-2.

3.0 Electrical characteristics

3.1 Interface signals

The input signals can be applied in two different modes :

- 1). Video, Hsync., Vsync.
2). Video, Composite Sync

Video : 0.7 Vp-p, input impedance, 75 ohm

Sync. : Separatesync TTL level, input
 impedance 2k2 ohm
 Hor. sync Positive/Negative
 Ver. sync Positive/Negative

Composite sync TTL level, input
 impedance 2k2 ohm
 Positive/Negative

3.2 Interface

3.2.1 Cable

The input signals are applied to the display through a detachable shielded cable.

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.	31	590	—	5	10
TY		CHECK	DATE 2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

PHILIPS



Length : 1.5 m +/- 50 mm (detachable)

Connector type : 15 pin D-Sub male to 15 pin D-Sub male, blue
IBM PS/2 standard (3 rows)
with DDC 2B pin assignments

pin assignments :

pin no.	
1	Red video input
2	Green video input
3	Blue video input
4	Optional - connected to pin 10
5	Not connected
6	Red video ground
7	Green video ground
8	Blue video ground
9	+5V
10	Sync ground
11	Optional - connected to pin 10
12	Bi-directional data (SDA)
13	HH+V sync
14	V sync (VCLK)
15	Data clock (SCL)

All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

2002-03-14

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 6	10 A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

- 3.2.2 Adaptor 15 pin D-standard (2 rows male) to 15 pin D-sub (female)
for Apple Macintosh II use.(Option)

pin assignments :

pin no	15 Pin D-standard
1	RED GND
2	RED VIDEO
3	COMPOSITE SYNC
4	SYNC GND
5	GREEN VIDEO
6	GREEN GND
7	NC
8	NC
9	BLUE VIDEO
10	NC
11	NC
12	NC
13	BLUE GND
14	NC
15	NC

CLASS NO.

21" AUTO SCAN CMTR

TYPE : 201B40/00C-M25P-201B4
BRAND : PHILIPS

8639 000 11832

2002-01-23

NAME ALEX CHEN

SUPERS.

31

590

— 7

10

A4

TY

CHECK

DATE 2002-01-23

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

3.2.3 Software control functions via OSD/control

- Adjustable functions:

Main Controls
Language
Zoom
Adjust horizontal
Adjust vertical
Adjust shape
Adjust color
Reset to factory settings
Extra Controls
Close Main Controls
Move selection then

Language

-Language : multi-language(at least 5 language)

Input

-Input signal selection

Zoom

- Zoom

Adjust horizontal

-Adjust position
-Adjust size

Adjust vertical

-Adjust position
-Adjust size

Adjust shape

-Adjust side curve
Pincushion
Balanced
-Adjust side angles
Trapezoid
Parallelogram
-Rotate image
Rotate

CLASS NO.

21" AUTO SCAN CMTR

TYPE : 201B40/00C-M25P-201B4

BRAND : PHILIPS

8639 000 11832

2002-01-23

NAME ALEX CHEN

SUPERS.

31

590

8

10

A4

TY

CHECK

DATE

2002-01-23

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS



Adjust color
 -9300K for general use
 -6500K for image management
 -5500K for photoretouch

-sRGB
 - User preset

Reset to factory settings
 - No
 -Yes

Extra Controls

Adjust moir

Horizontal
 Vertical

!

degauss

-
 -Auto calibrate

3.3 Timing requirement

3.3.1 Mode storing capacity

Total modes available : 50
 (1) Factory modes : 34 (Including 7 preset mode)
 (2) User modes : 16

3.3.2 Factory preset timings

The factory settings of size and centering are according to the reference timing charts (see fig-8, fig-9)

All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 9	10 A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

MODE NO.	1	2	3	4
RESOLUTION	640 x 480	720 x 400	640 x 480	640 x 480
Dot clock(MHz)	25.175	28.321	31.500	31.500
f h	31.469 kHz	31.468 kHz	37.500 KHz	37.861 kHz
A (us)	31.778	31.778	26.667	26.413
B (us)	3.813	3.813	2.032	1.270
C (us)	1.907	1.907	3.810	3.810
D (us)	25.422	25.423	20.317	20.317
E (us)	0.636	0.325	0.508	1.016
f v	59.941 Hz	70.084 Hz	75.000 Hz	72.810 Hz
O (ms)	16.683	14.268	13.333	13.735
P (ms)	0.064	0.064	0.080	0.079
Q (ms)	1.049	1.112	0.427	0.528
R (ms)	15.253	12.711	12.800	12.678
S (ms)	0.317	0.382	0.026	0.45
SYNC. H/V	- / -	- / +	- / -	- / -
POLARITY				
SEP . SYNC	Y	Y	Y	Y

MODE NO.	5	6	7	8
RESOLUTION	800x600	640 x 480	800 x 600	800 x 600
Dot clock(MHz)	40.000	36.000	49.500	50.000
f h	37.879 kHz	43.269 kHz	46.875 kHz	48.077 kHz
A (us)	26.400	23.111	21.333	20.800
B (us)	3.200	1.556	1.616	2.400
C (us)	2.200	2.222	3.232	1.280
D (us)	20.000	17.778	16.162	16.000
E (us)	1.000	1.555	0.323	1.12
f v	60.317Hz	85.008 Hz	75.000 Hz	72.188 Hz
O (ms)	16.579	11.763	13.333	13.853
P (ms)	0.106	0.069	0.064	0.125
Q (ms)	0.607	0.578	0.448	0.478
R (ms)	15.840	11.093	12.800	12.480
S (ms)	0.026	0.023	0.021	0.77
SYNC. H/V	+ / +	- / -	+ / +	+ / +
POLARITY				
SEP . SYNC	Y	Y	Y	Y

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	10
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

MODE NO.	9	10	11	12
RESOLUTION	1024 x 768	832 x 624	640 x 480	800 x 600
Dot clock(MHz)	65.000	57.280	40.500	56.250
f h	48.363 kHz	49.722 kHz	50.628 kHz	53.674 kHz
A (us)	20.677	20.110	19.752	18.631
B (us)	2.092	1.117	1.580	1.138
C (us)	2.462	3.910	1.975	2.702
D (us)	15.754	14.520	15.802	14.222
E (us)	0.369	0.563	0.395	0.569
f v	60.004 Hz	74.546 Hz	100.10 Hz	85.061 Hz
O (ms)	16.666	13.410	9.995	11.756
P (ms)	0.124	0.060	0.059	0.056
Q (ms)	0.600	0.784	0.435	0.503
R (ms)	15.880	12.550	9.481	11.179
S (ms)	0.062	0.016	0.020	0.018
SYNC. H/V	- / -	+ / +	- / -	+ / +
POLARITY				
SEP . SYNC	Y	Y	Y	Y

MODE NO.	13	14	15	16
RESOLUTION	1024 x 768	1024 x 768	800 x 600	1280 x 1024
Dot clock(MHz)	75.000	78.750	67.500	108.000
f h	56.476 kHz	60.023 kHz	63.923 kHz	63.981 kHz
A (us)	17.707	16.660	15.644	15.630
B (us)	1.813	1.219	0.948	1.037
C (us)	1.920	2.235	2.370	2.296
D (us)	13.653	13.003	11.852	11.852
E (us)	0.321	0.203	0.474	0.445
f v	70.069 Hz	75.029 Hz	100.00 Hz	60.020 Hz
O (ms)	14.272	13.328	9.997	16.661
P (ms)	0.016	0.050	0.047	0.047
Q (ms)	0.513	0.466	0.548	0.594
R (ms)	13.599	12.795	9.387	16.005
S (ms)	0.054	0.017	0.015	0.015
SYNC. H/V	- / -	+ / +	+ / +	+ / +
POLARITY				
SEP . SYNC	Y	Y	Y	Y

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.	31	590	— 11	10	A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

MODE NO.	17	18	19	20
RESOLUTION	1024 x 768	1152 x 870	1600 x 1200	1280 x 1024
Dot clock(MHz)	94.500	100.000	162.000	135.00
f h	68.677 kHz	68.681 kHz	75.000 kHz	79.976 kHz
A (us)	14.561	14.560	13.333	12.504
B (us)	1.016	1.280	1.185	1.067
C (us)	2.201	1.440	1.877	1.837
D (us)	10.836	11.520	9.877	9.481
E (us)	0.508	0.32	0.394	0.119
f v	84.997 Hz	74.979 Hz	60.000 Hz	75.024 Hz
O (ms)	11.765	13.333	16.667	13.329
P (ms)	0.044	0.044	0.040	0.038
Q (ms)	0.524	0.568	0.613	0.475
R (ms)	11.183	12.678	16.000	12.804
S (ms)	0.014	0.043	0.014	0.012
SYNC. H/V	+ / +	- / -	+ / +	+ / +
POLARITY				
SEP . SYNC	Y	Y	Y	Y

MODE NO.	21	22	23	24
RESOLUTION	1600 x 1200	1792 x 1344	1856 x 1392	1600 x 1200
Dot clock(MHz)	175.500	204.750	218.250	189.000
f h	81.250 kHz	83.640 kHz	86.333 kHz	87.500 kHz
A (us)	12.308	11.956	11.583	11.429
B (us)	1.094	0.977	1.026	1.016
C (us)	1.732	1.602	1.489	1.608
D (us)	9.117	8.752	8.504	8.466
E (us)	0.365	0.625	0.564	0.339
f v	65.000 Hz	59.999 Hz	59.995 Hz	70.000 Hz
O (ms)	15.385	16.667	16.668	14.286
P (ms)	0.037	0.036	0.035	0.034
Q (ms)	0.566	0.550	0.498	0.526
R (ms)	14.769	16.069	16.124	13.715
S (ms)	0.013	0.012	0.011	0.011
SYNC. H/V	+ / +	+ / +	+ / +	+ / +
POLARITY				
SEP . SYNC	Y	Y	Y	Y

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	12
TY		CHECK	DATE 2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

MODE NO.	25	26	27	28
RESOLUTION	1920 x 1440	1280 x 1024	1600 x 1200	1600 x 1200
Dot clock(MHz)	234.000	157.500	202.500	229.500
f h	90.000 kHz	91.146 kHz	93.750 kHz	106.250 kHz
A (us)	11.111	10.971	10.667	9.412
B (us)	0.889	1.016	0.948	0.837
C (us)	1.470	1.422	1.501	1.325
D (us)	8.205	8.127	7.901	6.972
E (us)	0.547	0.406	0.317	0.278
f v	60.000 Hz	85.024 Hz	75.000 Hz	85.000 Hz
O (ms)	16.667	11.761	13.334	11.765
P (ms)	0.033	0.033	0.032	0.028
Q (ms)	0.622	0.483	0.491	0.433
R (ms)	16.000	11.234	12.800	11.294
S (ms)	0.012	0.011	0.011	0.01
SYNC. H/V	+ / +	+ / +	+ / +	+ / +
POLARITY				
SEP . SYNC	Y	Y	Y	Y

MODE NO.	29	30	31	32
RESOLUTION	1792 x 1344	1856x1392	1920x1440	1792x1344
Dot clock(MHz)	261.000	279.713	297	281.014
f h	106.270 kHz	109.950 kHz	112.5 kHz	114.048
A (us)	9.410	9.095	8.889	8.768
B (us)	0.828	0.715	0.754	0.712
C (us)	1.349	1.23	1.185	1.196
D (us)	6.866	6.635	6.465	6.377
E (us)	0.367	0.515	0.485	0.483
f v	74.997 Hz	75Hz	75Hz	81Hz
O (ms)	13.334	13.333	13.333	12.346
P (ms)	0.028	0.027	0.027	0.026
Q (ms)	0.649	0.636	0.636	0.526
R (ms)	12.647	12.66	12.66	11.785
S (ms)	0.01	0.01	0.008	0.009
SYNC. H/V	+ / +	+ / +	+ / +	+ / +

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	13
TY		CHECK	DATE 2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

MODE NO.	33	34
RESOLUTION	1280x1024	1600x1200
Dot clock(MHz)	202.815	254.446
f h	115.236kHz	115.238kHz
A (us)	8.678	8.678
B (us)	0.710	0.692
C (us)	1.183	1.195
D (us)	6.311	6.288
E (us)	0.474	0.503
f v	106.7Hz	91.758Hz
O (ms)	9.372	10.899
P (ms)	0.026	0.026
Q (ms)	0.451	0.451
R (ms)	8.886	10.413
S (ms)	0.009	0.009
SYNC. H/V POLARITY	+ / +	+ / +
SEP . SYNC	Y	Y

3.3.3 Horizontal scanning

Sync polarity : Positive or Negative
 Scanning frequency : 30 - 115 KHz
 Retrace time : 1.8 sec (typical)

3.3.4 Vertical scanning

Sync polarity : Positive or Negative
 Scanning frequency : 50 - 160 Hz

3.4 Power input connection

Power cord length : 1.5 M
 Power cord type : 3 leads detachable power cord with protective earth plug.

3.5 Video amplifiers

Rise time/Fall time : 4.0 / 4.5 ns
 (excluding rise/fall time due to test pattern & test probe)
 Overshoot/undershoot : Max. 12%
 Black level shift : Max. 3%
 Sag : Max. 5%

CLASS NO.

21" AUTO SCAN CMTR

TYPE : 201B40/00C-M25P-201B4

BRAND : PHILIPS

8639 000 11832

2002-01-23

NAME ALEX CHEN

SUPERS.

31

590

— 14

10

A4

TY

CHECK

DATE

2002-01-23

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

Go to cover page

PHILIPS



3.6 Degaussing

An automatic degaussing circuit is provided and required no intervention. The degaussing is activated at the time of switch-on and power saving wake up or switch-on again after switched-off for longer than 30 minutes. Manual degaussing is provided to eliminate any color impurity.

3.7 Requirement for low emission

- (1) Electro static potential : < 0.5 KV
(2) Alternating Elec. field

ELF 5 - 2 KHz : 10.0 V/M
VLF 2 - 400 KHz : 1.0 V/M

(3) Magnetic field

ELF 5 - 2 KHz : 200 nT
VLF 2 - 400 KHz : 25 nT

3.8 Power management

The power consumption and the status indication of the set with power management function are as follows,

STATUS	Horizontal	Vertical	Power Spec	LED
On	Pulse	Pulse	as normal on	Green
OFF	No Pulse	Pulse	< 2 W	Yellow
OFF	Pulse	No Pulse	< 2 W	Yellow
OFF	No Pulse	No Pulse	< 2 W	Yellow

Compliant with TCO99 power saving requirement
EPA energy star requirement
E2000

All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

CLASS NO.		21" AUTO SCAN CMTR		8639 000 11832	
		TYPE : 201B40/00C-M25P-201B4			
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 15	10 A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	



3.9 Display identification

In accordance with VESA Display Channel Standard and having DDC 2B capability

4.0 Visual characteristics

4.1 Test conditions

Unless otherwise specified, this specification is defined under the following conditions.

- (1) Input signal: As defined in 3.3, 1024 x 768 non-interlaced mode (68.7 KHz), signal sources must have 75 ohm output impedance, with 0.7Vpp video level.
- (2) Luminance setting: controls to be set to 20 ft-lb with full screen 100% duty cycle white signal.
- (3) Warm up: more than 30 minutes after power on with signal supplied.
- (4) Ambient light: 400 -- 600 lux.
- (5) Ambient temperature: 20 ± 5 °C
- (6) Ambient magnetic field: no special ambient magnetic field existed. (the ac leakage flux, dc flux caused by transformer magnet, etc.)
- (7) CRT face: East

4.2 Resolution

Inspection modes :

Mode	Resolution	H. freq. / V. freq	Standard
1.	1024 x 768	60.023KHz/75.029Hz	(VESA/75)
2.	1024 x 768	68.677KHz/84.997Hz	(VESA/85)
3.	1280 x 1024	79.976KHz/75.024Hz	(VESA/75)
4.	1280 x 1024	91.146KHz/85.024Hz	(VESA/85)
5.	1600 x 1200	93.75KHz/75.000Hz	(VESA/75)
6.	1600 x 1200	106.25KHz/85.000Hz	(VESA/85)
7.	1792 x 1344	106.3KHz/75.000Hz	(VESA/75)
8.	1920x1440	112.5KHz/75Hz	(VESA/75)

!

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	16
TY	CHECK	DATE	2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



4.3 Brightness

Color Temp	Brightness control	Contrast control	White Square (see fig-5)	Full white
	MIN	MIN	-	-
	CENTER	MIN	-	< 0.1 ft-lb
@9300K	CENTER	MAX	32 ft-lb	30 ft-lb
@6500K	CENTER	MAX	28 ft-lb	-
@5500K	CENTER	MAX	25 ft-lb	-
@9300K	MAX	MAX	-	-

4.3.1 sRGB

Once press RGB function on OSD, the luminance shall be changed to 23+/- 3ft-lb and color temperature is matching to 6500°K, at white square pattern.

4.4 Flagwaving - jitter
Less than 0.15mm.

4.5 Image size

4.5.1 Actual display size

The dimensions of the data area, measured along the picture center of horizontal and vertical axis of the screen, are listed below: (see Fig 1)
(392 +/- 4 mm) X (294 +/- 4 mm)

4.5.2 Max scan size

Maximum active video size should be not smaller than mask opening. The mask opening is 406.4 x 304.8 mm.

4.6 Image centering deviation

|A-B| and |C-D| <= 6 mm, please see Fig 2

4.7 Picture shift range

H-shift range : total 30 mm.
V-shift range : total 15 mm.

4.8 Display dimension stability

Due to brightness : 1.0 %
Due to aging : 1.0 %
Due to mains voltage : 1.0 %
Dynamic : < 1mm

All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority from the proprietors.

CLASS NO.

21" AUTO SCAN CMTR

TYPE : 201B40/00C-M25P-201B4
BRAND : PHILIPS

8639 000 11832

2002-01-23

NAME ALEX CHEN

SUPERS.

31

590 — 17

10

A4

TY

CHECK

DATE 2002-01-23

Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD., B.E.



4.10 Picture tilt
1mm (see Fig.3)
User adjust range for tilt : 1 deg. min.

4.11 Image non-linearity
Horizontal:
Max. - Min. x 100 % 8 % (30 - 31.5KHz)
Max. + Min. 7 % (31.6 - 64.0KHz)
5 % (64.1 - 115 KHz)

For any two adjacent blocks 5 % (30 - 31.5KHz)
4 % (31.6 - 64.0KHz)
3 % (64.1 - 115 KHz)

Vertical : = 5 %
For any two adjacent blocks 3 %

4.12 Misconvergence

The maximum convergence error should be measured on a white line and represents the maximum distance between the center of the red, green and blue lines over the whole image area.

Max. misconception :
(Picture area 355X265 See Fig. 6)

Zone 31.5Khz 31.6 67Khz >67Khz
B 0.50 0.45 0.40
A 0.40 0.35 0.30
C 0.15 0.15 0.15

4.13 Focus check

First, adjust brightness to 50 % position and contrast to max., and then generate "" characters for 1024 lines to cover entire picture area (picture size is shown in sect. 4.5). Characters should be clearly identified at the center and all corners. Character size is shown in Fig.7.

4.14 Brightness uniformity

With an active video area full white pattern adjusted to brightness 50% and contrast 100%, no portion of the pattern shall be less than 75 % of the luminance measured at the CRT center.

4.15 White color adjustment

There are three factory preset white color 9300 K, 6500 K and 5500 K.

Apply full white pattern, with brightness in 50 % position and the contrast control at max. position.
The 1931 CIE Chromaticity (color triangle) diagram (x,y) coordinate for the screen center should be:

9300 K CIE coordinates X = 0.283 0.020

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	18
TY		CHECK	DATE 2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

9300 K CIE coordinates $X = 0.283 \quad 0.020$
 $Y = 0.297 \quad 0.020$

6500 K CIE coordinates $X = 0.313 \quad 0.020$
 $Y = 0.329 \quad 0.020$

5500 K CIE coordinates $X = 0.332 \quad 0.020$
 $Y = 0.347 \quad 0.020$

- 4.16 White uniformity
 Set the brightness control at center 50 % position, then adjust the contrast control to 100%. The color coordinate at any point on the screen should be :

$X = X(\text{center}) \quad 0.015$
 $Y = Y(\text{center}) \quad 0.015$

- 4.17 Color tracking on full white pattern
 Adjust the contrast control from max. to min.(with brightness at click position). The color coordinates should not deviate more than:

$x = x(\text{center}) \pm 0.015$
 $y = y(\text{center}) \pm 0.015$

- 4.18 Purity
 Conditions: With full color pattern, with brightness control at 50 % position and contrast control in maximum, under the specific destinations of earth magnetic environments.

- 4.19 Moire
 At 15FL contrast & moir is acceptable if not over 1/3 area..

- 4.20 Ringing
 Apply a full white pattern at 107KHz, set horizontal raster symmetrically by raster shift press the OSD button & select horizontal position shift the image to the left edge of the raster. the yoke ring should less than 10mm.

- 4.21 Tapping test
 No interference does disturb the monitor picture during tapping test with a rubber hammer.

- 4.22 Distance between two monitors
 Two monitors of the same monitor type which were conducted with different Modes or frequencies, don t show any inference in a distance down to 25cm.

5.0 Mechanical characteristics

- 5.1 Controls
- | | | |
|------------|---|-------------------|
| Front side | : | |
| | - | AC power switch |
| | - | OSD function key |
| Rear | : | |
| | - | D- sub / BNC |
| | - | Power cord socket |

CLASS NO.

21" AUTO SCAN CMTR

TYPE : 201B40/00C-M25P-201B4
 BRAND : PHILIPS

8639 000 11832

2002-01-23

NAME ALEX CHEN

SUPERS.

31

590

— 19

10

A4

TY

CHECK

DATE

2002-01-23

Property of

PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

- 4.21 Tapping test
No interference does disturb the monitor picture during tapping test with a rubber hammer.
- 4.22 Distance between two monitors
Two monitors of the same monitor type which were conducted with different Modes or frequencies, don't show any inference in a distance down to 25cm.

5.0 Mechanical characteristics

5.1 Controls

Front side:

- AC power switch
- OSD function key

Rear :

- D- sub / BNC
- Power cord socket

5.2 Unit dimension / Weight

Set dimension (incl. pedestal) : 482(W) x 476(H) x 467 (D) mm

Net weight : 24 ± 0.5 Kg

5.3 Tilt and swivel base

The display should be equipped with a tilt & swivel device allowing rotation over an angle of 90 degree left or rightward and for a tilt of -5 degree to +15 degree with respect to the horizontal position.

5.4 Transportation packages

5.4.1 Shipping dimension/Weight

Carton dimension : 557(W) x 627(H) x 596(D) mm

Gross weight : 28.0 ± 0.5Kg

5.4.2 Block unit / Polarization

<u>layers/block</u>	<u>sets/layer</u>	<u>sets/block unit</u>
3	4	12

<u>blocks/container</u>
<u>20 feet</u> <u>40 feet</u>
8 20

6.0 Environmental characteristics

The following sections define the interference and susceptibility condition limits that might occur between external environment and the display device.

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	— 20
TY		CHECK	DATE 2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



6.1 Susceptibility of display to external environment

Operating

- Temperature : 0 to 35 degree C
- Humidity : 10 to 90% (w/o condensation)
- Altitude : 10,000 ft

Storage

- Temperature : -40 to 60 degree C
- Humidity : 5 to 95% (w/o condensation)
- Altitude : 40,000 ft
- Condensation : should be prevented

6.2 Transportation tests

TEST ITEM	TEST CONDITION	STANDARD REFERENCE
1. PACKAGED TEST :		
1.1 Packaged random vibra. test 4 sets	*5 ~ 200 Hz, 0.73 Grms , *30 min/axis, 3 axes.,	Ref. ASTM D-4169
1.2 Drop test *4 sets after random vibra. Test	Drop Height: 45 CM *Sequence: 1C-3E-6F , 10 drops,	NSTA height increment one level NSTA
1.3 Cold drop test (Only for reference) 2 sets	*-10 C for 16 hours, recovery time after cold test: +/- 5 minutes *Gross weight drop height: 30 CM *Sequence: 1C-3F , 4 drops ,	UN-D1400 NSTA
2. UN-PACKAGED VIBRATION TEST :		
2.1 Operating random vibra. test 2 sets	*5~500 Hz, 0.25 Grms, *30 min/axis 3 axes.	Ref.OEM spec.
2.2 Shock test(half sine) 2 sets	a. 100 G , < 3 msec , 6 shocks *G value measurement filter: 330Hz #Exclude CRT impurity (Only for reference)	Ref.OEM spec

TOTAL : 10 sets

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	21
TY	CHECK	DATE	2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or issue to third parties in any form whatever is not permitted without written authority from the proprietors.

6.3 Display disturbances from external environment
According to IEC 801-2 for ESD disturbances

6.4 Display disturbances to external environment

6.4.1 Ionizatic radiation
Completely fulfilled International Commission of
Radiological Protection (ICRP) requirement 0.5 mR/hrs.

7.0 Reliability

7.1 Mean Time Between Failures
MTBF to be calculated according to military standard MIL-HDBK-217C.
MTBF > = 75,000 hrs (excluding CRT)

$$\text{Practice of MTBF} = \frac{\text{Total hrs (power on) x Total sets}}{\text{NO. of failed sets}}$$

8.0 Quality assurance requirements

8.1 Acceptance test
according to MIL-STD-105D Control II level

AQL : 0.65 (major)
2.50 (minor)
(please also refer to annual quality agreement)
Customer acceptance criteria : UAW0377/00

9.0 Serviceability
The serviceability of this monitor should fulfill the
requirements which are prescribed in UAW-0346 and must
be checked with the check list UAT-0361.

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 22	10 A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.





FIG-1 IMAGE DIMENSION

CLASS NO.		21" AUTO SCAN CMTR		8639 000 11832	
		TYPE : 201B40/00C-M25P-201B4			
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	23
TY	CHECK	DATE	2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.



$$|A-B| \text{ AND } |C-D| < 6 \text{ mm}$$

FIG-2 IMAGE CENTERING

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.	31	590	— 24	10	A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.





FIG-3 IMAGE ROTATION

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME ALEX CHEN		SUPERS.		31	590	25	10
TY		CHECK		DATE 2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.		

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.



$$A = B = 2.5 \text{ mm}$$

FIG-4 IMAGE GEOMETRY


CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	26
TY		CHECK	DATE 2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.



**FIG-5 BRIGHTNESS AND CONTRAST
MEASUREMENT AREA**

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832			
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.	31	590	— 27	10	A4
TY		CHECK	DATE 2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.			

PHILIPS



All rights strictly reserved. Reproduction or Issue
to third parties in any form whatever is not permitted
without written authority, from the proprietors.




FIG-6 MISCONVERGENCE

CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590	— 28
TY		CHECK	DATE 2002-01-23	10	A4
Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.					

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.

1 BYTE = 8BITS

LINE	HEX.DATA		7	6	5	4	3	2	1	0
0	0	0								
1	0	0								
2	3	C								
3	4	2								
4	4	2								
5	5	E								
6	5	2								
7	5	2								
8	5	C								
9	4	0								
A	3	C								
B	0	0								
C	0	0								
D	0	0								
E	0	0								
F	0	0								

Fig 7 CHARACTER FORMAT FOR FOCUS CHECK


CLASS NO.		21" AUTO SCAN CMTR			
		TYPE : 201B40/00C-M25P-201B4		8639 000 11832	
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 29	10 A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

PHILIPS




All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.


SEPARATE SYNC.




HORIZONTAL



VERTICAL



COMPOSITE SYNC.



HORIZONTAL



FIG-8 TIMING CHART -1


CLASS NO.		21" AUTO SCAN CMTR		8639 000 11832	
		TYPE : 201B40/00C-M25P-201B4			
		BRAND : PHILIPS			
2002-01-23					
NAME	ALEX CHEN	SUPERS.	31	590 — 30	10 A4
TY	CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.	

Go to cover page

PHILIPS



All rights strictly reserved. Reproduction or Issue to third parties in any form whatever is not permitted without written authority, from the proprietors.



**COMPOSITE SYNC. & VIDEO
(SYNC. ON GREEN)**





FIG-9 TIMING CHART -2

CLASS NO.		21" AUTO SCAN CMTR					
		TYPE : 201B40/00C-M25P-201B4			8639 000 11832		
		BRAND : PHILIPS					
2002-01-23							
NAME	ALEX CHEN	SUPERS.		31	590	— 31	10
TY		CHECK	DATE	2002-01-23	Property of PHILIPS ELECTRONICS INDUSTRIES (TAIWAN) LTD.-B.E.		

General Troubleshooting Guide



Note : Not all described feature are applicable for all monitors.

General Troubleshooting Guide

1


NO DISPLAY,
but LED is ON
or LED is amber(yellow)

Checkpoint:

1. No Macintosh adaptor attached to the plug of signal cable if using the IBM PC
2. A symptom of no color on models equipped with the Plug & Plug feature (DDC) may be seen when these monitors are connected to a NON-DDC Host or Computer.
Order a DDC Eliminator Adaptor, P/N 4822 263 50248 from our Customer Care Center.
3. Try to swap the selection of "BNC /Dsub" signal selector in the rear of monitor, if it has.
4. Try to swap the selection of "SOG/TTL"sync selector in the rear of monitor, if it has.
5. Keep pressing the OSD menu for a few seconds to expect a OSD control menu come out to select the "SOG / TTL sync"
6. Remove your USB cable from computer. Reboot computer in safe Mode or DOS mode
7. Disable the DDC 1/2B feature via OSD menu manipulation.
8. Click your mouse or type some word with your keyboard to wake up computer from saving status.
9. Check that your video cable is plugged in and does not have bent pins.

LED
Amber? or
Green?

Continued



General Troubleshooting Guide

Go to cover page

2

Monitor drivers (inf file)

for Windows 95/98/2000/Me or later

Philips' monitors build in VESA DDC2B feature to support Plug & Play requirement for Windows 95/98/2000/Me . You can install the information file (.inf) in order to select your Philips monitor from "Monitor" dialog box in Windows 95/98/2000/Me to activate Plug & Play application. The installation procedure based on Windows '95 OEM Release 2 , 98 , Me and 2000 is specified as follows, (In case of connecting the monitor to the PC compliant with VESA standard with the designated signal cable, the PC reads display pixels, frequency, and color feature of this monitor to optimise the picture for the monitor automatically.)
DDC : Abbreviation for Display Data Channel

**** Windows NT 4.0 does not inquire driver (inf file) for monitors.****

For Windows 98

But for Windows98 drivers, our monitors are listed under 2 manufactures name "Philips", "Philips Consumer Electronics Co". Please select "Philips" when you would like to set up your monitor in Windows setting , unless you can not find the right model name just as the label indication on the back of set. For those set that have been issued since the release of Win98 , drivers can be found in CDROM under the directory path of "\pc\ driver \" or it may be downloaded at "http: \www.philips.com". Once you have installed the new driver , Windows will add a new manufacture name "Philips Business Electronics" in your system.

For Windows Me

For Windows 2000

For Windows 95


For Windows95 drivers , our monitor is listed 1 manufacture name "Philips Business Electronics Co.".

1. Start Windows '95
2. Click the 'Start' button, point to 'Setting', and then click 'Control Panel'.
3. Double Click the 'Display' Icon.
4. Choose the 'Settings' tab then click 'Advanced...'
5. Choose 'Monitor' button, point to 'Change...' then click 'Have Disk...'
6. Click 'Browse...' button then choose the appropriate drive F: (CD-ROM Drive) then click 'OK' button.
7. Click the 'OK' button then choose your monitor model and click the 'OK'.
8. Click 'Close' button.

1. Start Windows 98
2. Click the 'Start' button, point to 'Setting', and then click 'Control Panel'.
3. Double Click the 'Display' Icon.
4. Choose the 'Settings' tab then click 'Advanced...'
5. Choose 'Monitor' button, point to 'Change...' then click 'Next'
6. Choose "Display a list of all the drivers in a specific location, so you can elect the driver you want." then click 'Next' and then click 'Have Disk...'
7. Click 'Browse...' button then choose the appropriate drive F: (CD-ROM Drive) then click 'OK' button.
8. Click the 'OK' button then choose your monitor model and click the 'Next' button then click 'Next' button.
9. Click 'Finish' button then the 'Close' button.

1. Start Windows Me
2. Click the 'Start' button, point to 'Setting', and then click 'Control Panel'.
3. Double Click the 'Display' Icon.
4. Choose the 'Settings' tab then click 'Advanced...'
5. Choose 'Monitor' button, then click 'Change...' button.
6. Choose "Specify the location of the driver (Advanced)" and click the 'Next' button.
7. Choose "Display a list of all the drivers in a specific location, so you can select the driver you want." then click 'Next' and then click 'Have Disk...'
8. Click 'Browse...' button then choose the appropriate drive F: (CD-ROM Drive) then click 'OK' button.
9. Click the 'OK' button then choose your monitor model and click the 'Next' button then click 'Next' button.
10. Click 'Finish' button then the 'Close' button.

1. Start Windows 2000
2. Click the 'Start' button, point to 'Setting', and then click 'Control Panel'.
3. Double Click the 'Display' Icon.
4. Choose the 'Settings' tab then click 'Advanced...'
5. Choose 'Monitor' button
- If the 'Properties' button is inactive, it means your monitor is properly configured. Please stop installation.
- If the 'Properties' button is active. Click 'Properties' button. Please follow next step continually.
6. Click 'Driver' and then click on 'Update Driver...' then click on the 'Next' button.
7. Choose "Display a list of the known drivers for this device so that I can choose a specific driver" then click 'Next' and then click 'Have disk...'
8. Click 'Browse...' button then choose the appropriate drive F: (CD-ROM Drive).
9. Click the 'Open' button, then click the 'OK' button.
10. Choose your monitor model and click the 'Next' button then click 'Next' button.
11. Click 'Finish' button then the 'Close' button. If you can see the "Digital Signature Not Found" window then click the 'Yes' button.



Case study : P-Line Focus issue (107P10/20, 109P10/20, 201P10)

Symptom: Poor Focus, Blurry Picture, colored outlines around characters.

Possible Cause:

Convergence Issues:

What is Convergence : As we know the CRT is comprised of thousands of color phosphor dots, (red, Green, and Blue). Convergence is the alignment to ensure that the proper electron beam strikes the correct colored phosphor dot and the correct triad of phosphor dots. (Triad = a group of each colored phosphor dots forming a triangle / Bold below)
For a better photo refer to any of our CD ROM's under glossary of terms and Dot Pitch.

R G B R G B R G B
B R G B R G B R
R G B R G B R G B

Convergence is typically not adjustable by the customer.

On the P-Line with a Diamondtron CRT, Convergence can be found in the main menu under extra controls.

If convergence is misadjusted, it will appear out of focus to the untrained eye.

Looking closely may reveal that characters will have a colored outline around them. (Red, Green or Blue.), if so..

It is not a focus issue but a convergence alignment problem.

Cure: Using the On Screen Display of the monitor, adjust the Horz and Vert Convergence under extra controls in the menu.

General Troubleshooting Guide

4

DEGAUSSING

There are 3 states that degaussing device of monitor will execute.

Picture moves due to the degaussing device working after Select "DEGAUSS" (OSD screen or Front Control Knob) and press the OK button (front control of monitor), but it is normal.

1. Power on monitor.
2. The monitor wakes up from sleep mode.
3. "DEGAUSS" selection and execute it.

Degauss the set in the on screen menu.

Please be aware that many models will not degauss more than once within any given time period (up to 10 minutes).

This is due to the unit having a temperature sensitive resistor.

While the unit is degaussing, the resistor increases in value with heat and once it reaches a certain temperature, the resistance will rise and prevent voltage from reaching the degaussing coil. This is what stops the degauser,

and this device's resistance will decrease as it cools back off enabling the degauss to operate again. This is an intentional design and is a industry standard, not just Philips.

A nearby magnetic field may magnetize the CRT.

Move the unit to another location and perform degaussing as mentioned above.

If the unit has been recently moved, the earth's magnetic field may have magnetized the CRT.

Perform degaussing as mentioned above.

If the unit has been dropped, the CRT shadow mask may be loose.

OK

NO

END

It is need to check and
repair the monitor.

5

Picture distortion (Geometry)

Tip : *****

The best way to understand "Image control features (by "On Screen Display" or "Front Control Knob") is to minimize and maximize each control feature while viewing a full image on the screen. By performing this, the customer will immediately understand:

1. How "Image control features" effect the image.
2. How to use "Image control features" to optimize the image.

Some type of magnetic or electrical interference typically causes poor geometry in the picture and is not normally a defective monitor.
Try the monitor in another physical location before suspecting the monitor itself.

: Reset monitor to factory preset via OSD menu manipulation.
: Change monitor timing to work at the recommended resolution .

OK

NO

YES

END

Access the Geometry Menu in the "On-Screen-Display" (or "Front Control") of the Monitor. Perform necessary adjustments.

Find out the specific "Image problem"

1. H or V size
2. H or V position
3. Geometry
 - a. Pincushion
 - b. Balanced
 - c. Trapezoid
 - d. Parallelogram
 - e. Tilt

H or V size

H or V position

Geometry problem

Is the control available ?

YES

Optimize with Image feature controls

Is picture displayed normally?

NO

YES
END

It is need to check and repair the monitor.

6

**Unstable Picture/
Picture Flickers**

A low refresh rate or electrical interference typically causes flickering in the picture and is not normally a defective monitor:

=>Try the monitor in another physical location before suspecting the monitor itself and adjust the refresh rate to 75hz or higher.

The "refresh rate" is the term that describes the number of times the entire screen is vertically scanned within one second, which means that if the refresh rate is 85 Hz, then the screen will be refreshed 85 times per second.

The higher the refresh rate, the better the image stability (less flicker).

The user who works long hours in front of the monitor will need this benefit to avoid eye fatigue and stress.

=>To change the refresh rate, go into "Start/Settings / Control Pannel / Display / properties / Setting/Advance/Adaptor" Windows settings of the computer, the monitor will automatically adjust itself to the video card.


OK


NO


YES


END


Please contact your
dealer/reseller for
more information.











MOIRÉ

A fringe pattern arising from the interference between two superimposed line patterns. In a monitor it comes from the interference between the shadow mask pattern and the video information (video moiré), and between the shadow mask and the horizontal line pattern (scan moiré). It shows itself as wavy patterns on the screen and becomes more noticeable as monitor resolution increases. Since the video signals varies continuously, little can be done about video moiré. Scan moiré depends on the horizontal scanning frequency and can be alleviated by appropriate choice of this frequency. Autoscans (MultiSync) monitors, however, which operate over a range of scanning frequencies, may sometimes exhibit moiré in certain video modes.

Several sources can act as a catalyzer to produce Moire. They are : The CRT, shadow mask, the electron beam spot size, the resolution, video patterns, and the horizontal and vertical size.

[Go to cover page](#)

**OSD MAIN MENU
LOCKED**



Press and hold the OSD menu key for about 10 seconds ,
until picture displays "OSD MAIN MENU UNLOCKED"




OK

NO

YES

END

Please contact your
dealer/reseller for
more information.



General Troubleshooting Guide

14

Missing Color

1. Turn off monitor.
2. Disconnect video cable.
3. Turn on monitor.

Colors on warning signal OK ?

YES

Check video cable for bent pins, reseal it.

Signal cable pins OK ?

YES

1. Try system with another monitor.
2. Try monitor with another system.
3. Try changing in the application.

Is picture displayed normally?

NO


It is need to check and repair the monitor.

YES


END

There are 2 easy ways to determine the Missing color problem.


1. View an image that is supposed to be "White".
If one of the colors (RGB) is not functioning.
White can not be produced.
2. View an image that supposed to contain Red, Green and Blue.
Color problems will be apparent when one or more of these colors can not be displayed.




Cyan Color means that the red gun is missing.




Magenta or Purple Color means that the green gun is missing.





Yellow Color means that the blue gun is missing.






General Troubleshooting Guide





General Troubleshooting Guide



Features:
CustoMax for monitors is a software program for adjusting the screen geometry, color quality, image quality and hardware and software settings of your display.

19**Colorific**

Colorific is a color matching software that helps user match the monitor and printer to fulfill the requirement of WYSIWYG (what you see is what you get) . The Colorific software is the property of Sonnetech ,Ltd. Only certain Philips monitor Models are equipped with the software. If you have special interesting , please hit the web site "<http://www.colorific.com>".

The compatibility problem with Windows :

Colorific 4.2 or below issued before Sept 98 cannot run in Win98.

Colorific 4.24 (CM5800) manufactured before May 1998 and issued by Feb 98 can support Win 98.

Colorific4.3 can fully support in Win 98

20

USB

USB = Universal Serial Bus

USB automatically determines resources (like driver software and bus bandwidth) required by peripherals.

USB makes necessary resources available without user intervention.

It is designed to meet Microsoft Plug and Play (PnP) specification, meaning users can install, and hot-swap devices without long installation procedures and reboots.

It allows 127 devices to run at the same time on the bus.

USB bus provides two types of data transfer speed -- 1.5Mbps and 12Mbps and it can provide a maximum of 500mA of current to devices attached on the bus.

Universal means all peripherals share the same connector.


Serial simply defines devices can daisy chain together.

Universal Serial Bus 1.1, the de facto external connectivity standard for Mac and PC, has picked up the speed after its slow adoption by peripheral manufacturers, users and PC OEMs.

USB 2.0 :

Drafted by Compaq, Hewlett Packard, Intel, Lucent, Microsoft, NEC and Philips,

USB Specification version 2.0 will increase device data throughput up to 480Mbps, 40 times faster than USB 1.1 devices.



TELEVISION/MONITOR SAFETY GUIDELINES FOR THE PROFESSIONAL SERVICE TECHNICIAN

Safety Checks

After the original service problem has been corrected, a complete safety check should be made. Be sure to check over the entire set, not just the areas where you have worked. Some previous service may have left an unsafe condition, which could be unknowingly passed onto your customer. Be sure to check all of the following:

Fire and Shock Hazard

1. Be sure all components are positioned in such a way as to avoid the possibility of adjacent component shorts. This is especially important on those chassis which are transported to and from the service shop.
2. Never release a repaired unit unless all protective devices such as insulators, barriers, covers, strain reliefs, and other hardware have been installed in accordance with the original design.
3. Soldering and wiring must be inspected to locate possible cold solder joints, solder splashes, sharp solder points, frayed leads, pinched leads, or damaged insulation (including the ac cord). Be certain to remove loose solder balls and all other loose foreign particles.
4. Check across-the-line components and other components for physical evidence of damage or deterioration and replace if necessary. Follow original layout, lead length, and dress.
5. No lead or component should touch a receiving tube or a resistor rated at 1 watt or more. Lead tension around protruding metal surfaces or edges must be avoided.
6. Critical components having special safety characteristics are identified with an asterisk by the Ref. No. in the parts list and enclosed within a broken line * (where several critical components are grouped in one area) along with the safety symbols on the schematic diagrams and/or exploded views.
7. When servicing any unit, always use a separate isolation transformer for the chassis. Failure to use a separate isolation transformer may expose you to possible shock hazard, and may cause damage to servicing instruments.
8. Many electronic products use a polarized ac line cord (one wide pin on the plug.) Defeating this safety feature may create a potential hazard to the service and the user. Extension cords which do not incorporate the polarizing feature should never be used.
9. After reassembly of the unit, always perform a leakage test or resistance test from the line cord to all exposed metal parts of the cabinet. Also check all metal control shafts (with knobs removed), antenna terminals, handles, screws, etc. to be sure the unit may be safely operated without danger of electrical shock.

* Broken line

Implosion

1. All picture tubes used in current model receivers are equipped with an integral implosion system. Care should always be used, and safety glasses worn, whenever handling any picture tube. Avoid scratching or otherwise damaging the picture tube during installation.
2. Use only replacement tubes specified by the manufacturer.


X-radiation

1. Be sure procedures and instructions to all your service personnel cover the subject of X-radiation. Potential sources of X-rays in TV receivers are the picture tube and the high voltage circuits. The basic precaution which must be exercised is to keep the high voltage at the factory recommended level.
2. To avoid possible exposure to X-radiation and electrical shock, only the manufacturer's specified anode connectors must be used.
3. It is essential that the service technician has an accurate HV meter available at all times. The calibration of this meter should be checked periodically against a reference standard.
4. When the HV circuitry is operating properly there is no possibility of an X-radiation problem. High voltage should always be kept at the manufacturer's rated value—no higher—for optimum performance. Every time a color set is serviced, the brightness should be run up and down while monitoring the HV with a meter to be certain that the HV is regulated correctly and does not exceed the specified value. We suggest that you and your technicians review test procedures so that HV and HV regulation are always checked as a standard servicing procedure, and the reason for this prudent routine is clearly understood by everyone. It is important to use an accurate and reliable HV meter. It is recommended that the HV recorded on each customer's invoice, which will demonstrate a proper concern for the customer's safety.
5. When troubleshooting and making test measurements in a receiver with a problem of excessive high voltage, reduce the line voltage by means of a Variac to bring the HV into acceptable limits while troubleshooting. Do not operate the chassis longer than necessary to locate the cause of the excessive HV.

6. New picture tubes are specifically designed to withstand higher operating voltages without creating undesirable X-radiation. It is strongly recommended that any shop test fixture which is to be used with the new higher voltage chassis be equipped with one of the new type tubes designed for this service. Addition of a permanently connected HV meter to the shop test fixture is advisable. The CRT types used in these new sets should never be replaced with any other types, as this may result in excessive X-radiation.
7. It is essential to use the specified picture tube to avoid a possible X-radiation problem.
8. Most TV receivers contain some type of emergency "Hold Down" circuit to prevent HV from rising to excessive levels in the presence of a failure mode. These various circuits should be understood by all technicians servicing them, especially since many hold down circuits are inoperative as long as the receiver performs normally.

Leakage Current Cold Check

1. Unplug the ac line cord and connect a jumper between the two prongs of the plug.
2. Turn on the power switch.
3. Measure the resistance value between the jumpered ac plug and all exposed cabinet parts of the receiver, such as screw heads, antennas, and control shafts. When the exposed metallic part has a return path to the chassis, the reading should be between 1 megohm and 5.2 megohms. When the exposed metal does not have a return path to the chassis, the reading must be infinity. Remove the jumper from the ac line cord.



Leakage Current Hot Check

1. Do not use an isolation transformer for this test. Plug the completely reassembled receiver directly into the ac outlet.
2. Connect a 1.5k, 10w resistor paralleled by a 0.15µf. capacitor between each exposed metallic cabinet part and a good earth ground such as a water pipe, as shown above.
3. Use an ac voltmeter with at least 5000 ohms volt sensitivity to measure the potential across the resistor.
4. The potential at any point should not exceed 0.75 volts. A leakage current tester may be used to make this test; leakage current must not exceed 0.5 milliamps. If a measurement is outside of the specified limits, there is a possibility of shock hazard. The receiver should be repaired and rechecked before returning it to the customer.
5. Repeat the above procedure with the ac plug reversed. (Note: An ac adapter is necessary when a polarized plug is used. Do not defeat the polarizing feature of the plug.)

Picture Tube Replacement

The primary source of X-radiation in this television receiver is the picture tube. The picture tube utilized in this chassis is specially constructed to limit X-radiation emissions. For continued X-radiation protection, the replacement tube must be the same type as the original, including suffix letter, or a Philips approved type.

Parts Replacement

Many electrical and mechanical parts in Philips television sets have special safety related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. The use of a substitute part which does not have the same safety characteristics as the Philips recommended replacement part shown in this service manual may create shock, fire, or other hazards.

WARNING: Before removing the CRT anode cap, turn the unit **OFF** and short the HIGH VOLTAGE to the CRT DAG ground.
SERVICE NOTE: The CRT DAG is not at chassis ground.